CONTAINER LOADING SITE RULES

TRUCK DRIVER CONDITIONS OF ENTRY

1. Obey instructions from Royal Wolf staff2. Speed limits and site signage MUST be obeyed3. Personal Protective Equipment (PPE) MUST be worn

VEHICLES WITHOUT TWIST LOCKS MUST –

Place the empty container on timber gluts/dunnage, rubber mats or friction matting Less than 4 twist locks? Chains must also be used to secure your load

1. Cross chain the container as per the diagram

No metal to metal contact

OR

2. Chain the empty container over each end using a minimum of 8mm chain and tensioning with turnbuckles or dogs on both sides

No metal to metal contact

3. The above direction is as per the National Transport Commissions Load Restraint Guide

