

Transactions		
Job	Date	Details
DRG003 : Atlas Copco F9C-11	10/07/2012	Parts
DRG003 : Atlas Copco F9C-11	12/07/2012	Ordering parts
DRG003 : Atlas Copco F9C-11	12/07/2012	Organise/ diagnose puts/ pick up parts oils
DRG003 : Atlas Copco F9C-11	13/07/2012	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	13/07/2012	Parts
DRG003 : Atlas Copco F9C-11	16/07/2012	Check hydraulic fluid leak
DRG003 : Atlas Copco F9C-11	16/07/2012	Check hydraulic leak
DRG003 : Atlas Copco F9C-11	18/07/2012	Adjust tracks as required
drg003 : Atlas Copco F9C-11	18/07/2012	Ground Engaging Tools
drg003 : Atlas Copco F9C-11	18/07/2012	Service
drg003 : Atlas Copco F9C-11	23/07/2012	Parts
DRG003 : Atlas Copco F9C-11	27/07/2012	Rect hoses off reel
drg003 : Atlas Copco F9C-11	30/07/2012	Service
DRG003 : Atlas Copco F9C-11	26/08/2012	Rect oil leak for engine compressor
DRG003 : Atlas Copco F9C-11	28/08/2012	Rect lubrication pressure fault
DRG003 : Atlas Copco F9C-11	4/09/2012	Rect coolant leak as required
DRG003 : Atlas Copco F9C-11	3/10/2012	Parts
DRG003 : Atlas Copco F9C-11	9/11/2012	Freight
drg003 : Atlas Copco F9C-11	30/11/2012	Parts
DRG003 : Atlas Copco F9C-11	8/12/2012	Check greaser for rocks inop elec fault
DRG003 : Atlas Copco F9C-11	8/12/2012	Grease switch
DRG003 : Atlas Copco F9C-11	10/12/2012	Change grease control
DRG003 : Atlas Copco F9C-11	13/12/2012	Replace shank
DRG003 : Atlas Copco F9C-11	14/12/2012	Parts
DRG003 : Atlas Copco F9C-11	21/12/2012	Parts
DRG003 : Atlas Copco F9C-11	21/12/2012	Service
DRG003 : Atlas Copco F9C-11	24/12/2012	Service
DRG003 : Atlas Copco F9C-11	9/01/2013	Check no start
DRG003 : Atlas Copco F9C-11	26/01/2013	Inspect & repair AC, found low on gas
DRG003 : Atlas Copco F9C-11	30/01/2013	Inspect samplers/dust collection operation
DRG003 : Atlas Copco F9C-11	31/01/2013	Parts
DRG003 : Atlas Copco F9C-11	31/01/2013	Parts
DRG003 : Atlas Copco F9C-11	31/01/2013	Parts
DRG003 : Atlas Copco F9C-11	2/02/2013	DRG T step tripping adjust
DRG003 : Atlas Copco F9C-11	3/02/2013	Continue with tracing E stap issues
DRG003 : Atlas Copco F9C-11	3/02/2013	Drill rig e-shop fault
DRG003 : Atlas Copco F9C-11	3/02/2013	E stop fact code
DRG003 : Atlas Copco F9C-11	4/02/2013	Parts
DRG003 : Atlas Copco F9C-11	5/02/2013	Parts
DRG003 : Atlas Copco F9C-11	9/02/2013	Tale atlas mechanic to rig to inspect
DRG003 : Atlas Copco F9C-11	10/02/2013	After hours call out
DRG003 : Atlas Copco F9C-11	11/02/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	12/02/2013	Assist with found hose leak
DRG003 : Atlas Copco F9C-11	12/02/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	12/02/2013	Parts
DRG003 : Atlas Copco F9C-11	12/02/2013	Remove & replace blown hydraulic hose
DRG003 : Atlas Copco F9C-11	12/02/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	14/02/2013	Inspect operation of boom lift
DRG003 : Atlas Copco F9C-11	14/02/2013	Wash unit check over

DRG003 : Atlas Copco F9C-11	15/02/2013	Clean, service, replace hyd hoses
DRG003 : Atlas Copco F9C-11	15/02/2013	Refit drifter chain
DRG003 : Atlas Copco F9C-11	16/02/2013	Finish service minor repairs
DRG003 : Atlas Copco F9C-11	18/02/2013	Check over
DRG003 : Atlas Copco F9C-11	23/02/2013	4X hydraulic hoses
DRG003 : Atlas Copco F9C-11	23/02/2013	Make clamp hoses
DRG003 : Atlas Copco F9C-11	23/02/2013	Replace hydraulic hoses on clamps
DRG003 : Atlas Copco F9C-11	26/02/2013	Fix oil leak
DRG003 : Atlas Copco F9C-11	28/02/2013	Parts
DRG003 : Atlas Copco F9C-11	1/03/2013	Parts
DRG003 : Atlas Copco F9C-11	2/03/2013	Remove & replace drifter
DRG003 : Atlas Copco F9C-11	2/03/2013	Remove end replace drifter
DRG003 : Atlas Copco F9C-11	3/03/2013	Diagnose fault with drifter, found it was rebuilt
DRG003 : Atlas Copco F9C-11	4/03/2013	Get machine to pump grease make new line
DRG003 : Atlas Copco F9C-11	4/03/2013	Parts
DRG003 : Atlas Copco F9C-11	5/03/2013	Finish of f minor repair to unit
DRG003 : Atlas Copco F9C-11	7/03/2013	Find problem with vaccumm
DRG003 : Atlas Copco F9C-11	8/03/2013	Parts
DRG003 : Atlas Copco F9C-11	8/03/2013	Repairs to drifter hyd
DRG003 : Atlas Copco F9C-11	9/03/2013	Inspect/repair oil leak
DRG003 : Atlas Copco F9C-11	11/03/2013	Parts
DRG003 : Atlas Copco F9C-11	12/03/2013	Parts
DRG003 : Atlas Copco F9C-11	14/03/2013	Repairs to drifter replaced o ring in fitting
DRG003 : Atlas Copco F9C-11	15/03/2013	Replace broken bolts
DRG003 : Atlas Copco F9C-11	16/03/2013	Replace fitting on drifter
DRG003 : Atlas Copco F9C-11	18/03/2013	Service
DRG003 : Atlas Copco F9C-11	18/03/2013	Service engine
DRG003 : Atlas Copco F9C-11	19/03/2013	Parts
DRG003 : Atlas Copco F9C-11	21/03/2013	Hyrdualic hose
DRG003 : Atlas Copco F9C-11	23/03/2013	Rope up hyd hose
DRG003 : Atlas Copco F9C-11	23/03/2013	Tie hose back ontodrill rig
DRG003 : Atlas Copco F9C-11	25/03/2013	E stop issues, check AC & replace intake tube
DRG003 : Atlas Copco F9C-11	25/03/2013	Service
DRG003 : Atlas Copco F9C-11	26/03/2013	Electrical issues E stop
DRG003 : Atlas Copco F9C-11	26/03/2013	Inspect/ repair e-stop fault found
DRG003 : Atlas Copco F9C-11	27/03/2013	Control issues
DRG003 : Atlas Copco F9C-11	27/03/2013	Drill issues
DRG003 : Atlas Copco F9C-11	28/03/2013	Drifter & elecrtical issues
DRG003 : Atlas Copco F9C-11	28/03/2013	Electrical faults in cab
DRG003 : Atlas Copco F9C-11	28/03/2013	Parts
DRG003 : Atlas Copco F9C-11	28/03/2013	Parts
DRG003 : Atlas Copco F9C-11	29/03/2013	Repair loom along boom, refit hoses
DRG003 : Atlas Copco F9C-11	29/03/2013	Repairs to hosing & mounting
DRG003 : Atlas Copco F9C-11	29/03/2013	Set up filters etc
DRG003 : Atlas Copco F9C-11	30/03/2013	Repairs to get truck adjusted
DRG003 : Atlas Copco F9C-11	30/03/2013	Set up hoses
DRG003 : Atlas Copco F9C-11	31/03/2013	Fit joy stickdrifter not operating properly & clam
DRG003 : Atlas Copco F9C-11	1/04/2013	Assist check operation
DRG003 : Atlas Copco F9C-11	1/04/2013	Parts
DRG003 : Atlas Copco F9C-11	3/04/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	4/04/2013	Parts

DRG003 : Atlas Copco F9C-11	5/04/2013	Inspect drill mode button, needs to be replaced
DRG003 : Atlas Copco F9C-11	6/04/2013	Hyd hoses
DRG003 : Atlas Copco F9C-11	9/04/2013	Inspect fault with felden functions, suspect can c
DRG003 : Atlas Copco F9C-11	10/04/2013	Extract broken bolts re set hoses
DRG003 : Atlas Copco F9C-11	10/04/2013	Remove broken bolt
DRG003 : Atlas Copco F9C-11	11/04/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	11/04/2013	Repairs to hoses & hose holdens on booms, repla
DRG003 : Atlas Copco F9C-11	12/04/2013	Finish assembling hoses & wiring
DRG003 : Atlas Copco F9C-11	15/04/2013	Parts
DRG003 : Atlas Copco F9C-11	16/04/2013	Parts
DRG003 : Atlas Copco F9C-11	20/04/2013	Replace shank belt & burst hole
DRG003 : Atlas Copco F9C-11	22/04/2013	Repairs to leaks on drifter
DRG003 : Atlas Copco F9C-11	23/04/2013	Parts
DRG003 : Atlas Copco F9C-11	23/04/2013	Replace R/hand key pad
DRG003 : Atlas Copco F9C-11	23/04/2013	Service adjust chains, find leak & wash
DRG003 : Atlas Copco F9C-11	24/04/2013	Freight
DRG003 : Atlas Copco F9C-11	24/04/2013	Parts
DRG003 : Atlas Copco F9C-11	26/04/2013	Begin to diagnose fault
DRG003 : Atlas Copco F9C-11	26/04/2013	Inspect woring fault, can loom rubbed again
DRG003 : Atlas Copco F9C-11	26/04/2013	Parts
DRG003 : Atlas Copco F9C-11	27/04/2013	Replace blown reel hose
DRG003 : Atlas Copco F9C-11	28/04/2013	Remove leaking hosem recummp hose
DRG003 : Atlas Copco F9C-11	29/04/2013	Diagnose AC tx valve at fault
DRG003 : Atlas Copco F9C-11	29/04/2013	Parts
DRG003 : Atlas Copco F9C-11	29/04/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	30/04/2013	Parts
DRG003 : Atlas Copco F9C-11	1/05/2013	Diagnose & repair hosing
DRG003 : Atlas Copco F9C-11	1/05/2013	Get new pant
DRG003 : Atlas Copco F9C-11	1/05/2013	Parts
DRG003 : Atlas Copco F9C-11	1/05/2013	Replaced blown drifter hoses
DRG003 : Atlas Copco F9C-11	2/05/2013	Look out oil leak
DRG003 : Atlas Copco F9C-11	2/05/2013	Parts
DRG003 : Atlas Copco F9C-11	2/05/2013	Precussion to worn diagnose engine oil leak
DRG003 : Atlas Copco F9C-11	3/05/2013	Parts
DRG003 : Atlas Copco F9C-11	3/05/2013	Parts
DRG003 : Atlas Copco F9C-11	3/05/2013	Parts
DRG003 : Atlas Copco F9C-11	3/05/2013	Remove & fit hue pump
DRG003 : Atlas Copco F9C-11	4/05/2013	Fit & test hue pump & timing
DRG003 : Atlas Copco F9C-11	6/05/2013	Make new hose
DRG003 : Atlas Copco F9C-11	7/05/2013	Freight
DRG003 : Atlas Copco F9C-11	7/05/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	7/05/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	7/05/2013	Parts
DRG003 : Atlas Copco F9C-11	7/05/2013	Parts
DRG003 : Atlas Copco F9C-11	7/05/2013	Parts
DRG003 : Atlas Copco F9C-11	7/05/2013	Parts
DRG003 : Atlas Copco F9C-11	8/05/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	8/05/2013	Parts
DRG003 : Atlas Copco F9C-11	8/05/2013	Parts
DRG003 : Atlas Copco F9C-11	13/05/2013	Service
DRG003 : Atlas Copco F9C-11	14/05/2013	Remove & replace t x valve so remove

DRG003 : Atlas Copco F9C-11	20/05/2013	Replace hose, repair light wiring
DRG003 : Atlas Copco F9C-11	21/05/2013	Air awitch & hydraulic
DRG003 : Atlas Copco F9C-11	21/05/2013	Call out to drill rig
DRG003 : Atlas Copco F9C-11	22/05/2013	Repair wipers
DRG003 : Atlas Copco F9C-11	23/05/2013	Hyd hose adjust feed chain carasoul issues chang
DRG003 : Atlas Copco F9C-11	24/05/2013	Check AC
DRG003 : Atlas Copco F9C-11	24/05/2013	Repairs & track to pit
DRG003 : Atlas Copco F9C-11	26/05/2013	Carousel repairs re fine & clean sensors tighten f
DRG003 : Atlas Copco F9C-11	27/05/2013	Parts
DRG003 : Atlas Copco F9C-11	27/05/2013	Repairs to loom
DRG003 : Atlas Copco F9C-11	28/05/2013	Parts
DRG003 : Atlas Copco F9C-11	29/05/2013	Parts
DRG003 : Atlas Copco F9C-11	29/05/2013	Parts
DRG003 : Atlas Copco F9C-11	31/05/2013	Find can cable
DRG003 : Atlas Copco F9C-11	31/05/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	4/06/2013	Adjust parameters & repair oil leak
DRG003 : Atlas Copco F9C-11	4/06/2013	Reet hyd leak & fittings
DRG003 : Atlas Copco F9C-11	5/06/2013	Parts
DRG003 : Atlas Copco F9C-11	5/06/2013	Parts
DRG003 : Atlas Copco F9C-11	5/06/2013	Parts
DRG003 : Atlas Copco F9C-11	7/06/2013	Parts
DRG003 : Atlas Copco F9C-11	7/06/2013	Repairs & service
DRG003 : Atlas Copco F9C-11	7/06/2013	Service check air con
DRG003 : Atlas Copco F9C-11	8/06/2013	Repairs assist copco
DRG003 : Atlas Copco F9C-11	9/06/2013	Continue repairs
DRG003 : Atlas Copco F9C-11	11/06/2013	Parts
DRG003 : Atlas Copco F9C-11	11/06/2013	Parts
DRG003 : Atlas Copco F9C-11	13/06/2013	Fit new can cable & battery fox door
DRG003 : Atlas Copco F9C-11	13/06/2013	Parts
DRG003 : Atlas Copco F9C-11	13/06/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	14/06/2013	Parts
DRG003 : Atlas Copco F9C-11	19/06/2013	Prep drill rig for A/C change
DRG003 : Atlas Copco F9C-11	20/06/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	20/06/2013	Parts
DRG003 : Atlas Copco F9C-11	20/06/2013	Parts
DRG003 : Atlas Copco F9C-11	20/06/2013	Remove & replace air con comp, vacuum
DRG003 : Atlas Copco F9C-11	20/06/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	21/06/2013	Parts
DRG003 : Atlas Copco F9C-11	21/06/2013	Parts
DRG003 : Atlas Copco F9C-11	22/06/2013	Repairs to can cables clean up wiring replace
DRG003 : Atlas Copco F9C-11	23/06/2013	Adjust tracks
DRG003 : Atlas Copco F9C-11	23/06/2013	Parts
DRG003 : Atlas Copco F9C-11	26/06/2013	Calibrate feed adjust L/H tack
DRG003 : Atlas Copco F9C-11	30/06/2013	Repairs to carousel
DRG003 : Atlas Copco F9C-11	1/07/2013	Change air filter door locks x4
DRG003 : Atlas Copco F9C-11	4/07/2013	Parts
DRG003 : Atlas Copco F9C-11	4/07/2013	Repairs
DRG003 : Atlas Copco F9C-11	5/07/2013	Replace dust hood ram replace grease nipples
DRG003 : Atlas Copco F9C-11	6/07/2013	Change ECL lucrication, cappillary
DRG003 : Atlas Copco F9C-11	8/07/2013	Parts
DRG003 : Atlas Copco F9C-11	8/07/2013	Parts

DRG003 : Atlas Copco F9C-11	9/07/2013	Parts
DRG003 : Atlas Copco F9C-11	10/07/2013	Parts
DRG003 : Atlas Copco F9C-11	12/07/2013	Electrical diagnosis
DRG003 : Atlas Copco F9C-11	12/07/2013	Parts
DRG003 : Atlas Copco F9C-11	12/07/2013	Repairs, locate loom
DRG003 : Atlas Copco F9C-11	13/07/2013	Assist diagnosis and pin check of boom loom
DRG003 : Atlas Copco F9C-11	13/07/2013	Diagnose can fault
DRG003 : Atlas Copco F9C-11	14/07/2013	Diagnose and rectify
DRG003 : Atlas Copco F9C-11	14/07/2013	Loom repairs & calibration adjustment
DRG003 : Atlas Copco F9C-11	14/07/2013	Parts
DRG003 : Atlas Copco F9C-11	15/07/2013	Diagnose no start order parts list
DRG003 : Atlas Copco F9C-11	16/07/2013	Check accumulator, adjust low side
DRG003 : Atlas Copco F9C-11	16/07/2013	Diagnostics
drg003 : Atlas Copco F9C-11	16/07/2013	Parts
DRG003 : Atlas Copco F9C-11	16/07/2013	Service
DRG003 : Atlas Copco F9C-11	17/07/2013	Diagnose fault & adjust machine to spec
DRG003 : Atlas Copco F9C-11	17/07/2013	Parts
DRG003 : Atlas Copco F9C-11	19/07/2013	Modify pressure switch did not work, bring to w/
DRG003 : Atlas Copco F9C-11	20/07/2013	200 hr service
DRG003 : Atlas Copco F9C-11	22/07/2013	Parts
DRG003 : Atlas Copco F9C-11	23/07/2013	Diagnose pressure fault
DRG003 : Atlas Copco F9C-11	23/07/2013	Parts
DRG003 : Atlas Copco F9C-11	24/07/2013	Organise solinoid problem & sort parts
DRG003 : Atlas Copco F9C-11	29/07/2013	Parts
DRG003 : Atlas Copco F9C-11	29/07/2013	Parts
DRG003 : Atlas Copco F9C-11	1/08/2013	Parts
DRG003 : Atlas Copco F9C-11	3/08/2013	Diagnose hyd leak, remove burst hyd hose
DRG003 : Atlas Copco F9C-11	4/08/2013	Remove & replace shank
DRG003 : Atlas Copco F9C-11	6/08/2013	Service & remove & replace hoses
DRG003 : Atlas Copco F9C-11	6/08/2013	Workshop Consumables
DRG003 : Atlas Copco F9C-11	7/08/2013	Parts
DRG003 : Atlas Copco F9C-11	7/08/2013	Remove & replace reel slides & guide plates
DRG003 : Atlas Copco F9C-11	8/08/2013	Parts
DRG003 : Atlas Copco F9C-11	8/08/2013	Parts
DRG003 : Atlas Copco F9C-11	8/08/2013	Remove & replace drifter slides & remove & repl
DRG003 : Atlas Copco F9C-11	9/08/2013	Alter supplied hoses to correct length, fit all ho
DRG003 : Atlas Copco F9C-11	10/08/2013	Change orientation of hoses over
DRG003 : Atlas Copco F9C-11	10/08/2013	Finish cleaning up/diagnose electrical fault with
DRG003 : Atlas Copco F9C-11	11/08/2013	Continue diagnosis of canbus system
DRG003 : Atlas Copco F9C-11	11/08/2013	Diagnose, can-bus system innoperative, faulting
DRG003 : Atlas Copco F9C-11	12/08/2013	Assist diagnosis of electrical fault in can bus
DRG003 : Atlas Copco F9C-11	12/08/2013	Diagnose can bus replace IO modul
DRG003 : Atlas Copco F9C-11	13/08/2013	Continue diagnosis make looms clean up arm
DRG003 : Atlas Copco F9C-11	13/08/2013	Continue diagnosis, electrical fault
DRG003 : Atlas Copco F9C-11	13/08/2013	General organisation & logistics for DRG003
DRG003 : Atlas Copco F9C-11	13/08/2013	Parts
DRG003 : Atlas Copco F9C-11	13/08/2013	Parts
DRG003 : Atlas Copco F9C-11	14/08/2013	Fit loomis still not good continue diagnostics
DRG003 : Atlas Copco F9C-11	14/08/2013	Parts/diagnosis can bus
DRG003 : Atlas Copco F9C-11	15/08/2013	Finsalise can bus diagnosis, adjust & align hose r
DRG003 : Atlas Copco F9C-11	15/08/2013	Repairs to con bus assist atlas with hose reels

DRG003 : Atlas Copco F9C-11	16/08/2013	Parts
DRG003 : Atlas Copco F9C-11	16/08/2013	Replace rock drill
DRG003 : Atlas Copco F9C-11	19/08/2013	Parts
DRG003 : Atlas Copco F9C-11	19/08/2013	Parts
DRG003 : Atlas Copco F9C-11	20/08/2013	Freight
DRG003 : Atlas Copco F9C-11	20/08/2013	Parts
DRG003 : Atlas Copco F9C-11	20/08/2013	Parts
DRG003 : Atlas Copco F9C-11	20/08/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	21/08/2013	Parts
DRG003 : Atlas Copco F9C-11	21/08/2013	Parts
DRG003 : Atlas Copco F9C-11	21/08/2013	Parts
DRG003 : Atlas Copco F9C-11	22/08/2013	Parts
DRG003 : Atlas Copco F9C-11	23/08/2013	Check routing of reel hoses
DRG003 : Atlas Copco F9C-11	23/08/2013	Parts
DRG003 : Atlas Copco F9C-11	24/08/2013	Remove blown hose, make hose re fit
DRG003 : Atlas Copco F9C-11	25/08/2013	Check routing of hammer hoses
DRG003 : Atlas Copco F9C-11	25/08/2013	Diagnose can fault repair and test
DRG003 : Atlas Copco F9C-11	26/08/2013	Check a/c and check hosing drain contaminated c
DRG003 : Atlas Copco F9C-11	26/08/2013	Got ot pit and check oil level of engine/ drain an
DRG003 : Atlas Copco F9C-11	26/08/2013	Parts
DRG003 : Atlas Copco F9C-11	26/08/2013	Service
DRG003 : Atlas Copco F9C-11	27/08/2013	Parts
DRG003 : Atlas Copco F9C-11	27/08/2013	Parts
DRG003 : Atlas Copco F9C-11	27/08/2013	Remove transfer pump and inspect/ front spool s
DRG003 : Atlas Copco F9C-11	28/08/2013	Diagnose and patch leaking compressor hose
DRG003 : Atlas Copco F9C-11	28/08/2013	Fit new transfer pump and injectors reprogram n
DRG003 : Atlas Copco F9C-11	28/08/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	29/08/2013	Check noisy turbo/ removed inlet and checked cc
DRG003 : Atlas Copco F9C-11	29/08/2013	Regas a/c diagnose high pitch noise at trubo on v
DRG003 : Atlas Copco F9C-11	30/08/2013	Ed fault replace sensor check AC temp
DRG003 : Atlas Copco F9C-11	30/08/2013	Parts
DRG003 : Atlas Copco F9C-11	30/08/2013	Parts
DRG003 : Atlas Copco F9C-11	30/08/2013	Repair compressor line leak
DRG003 : Atlas Copco F9C-11	31/08/2013	Attend & check hoses on drill
DRG003 : Atlas Copco F9C-11	1/09/2013	Preventative ,aintenance, change 1x-8 hose reel
DRG003 : Atlas Copco F9C-11	2/09/2013	Inspection
DRG003 : Atlas Copco F9C-11	2/09/2013	Repair compressir hose
DRG003 : Atlas Copco F9C-11	2/09/2013	Service
DRG003 : Atlas Copco F9C-11	2/09/2013	Workshop Tools
DRG003 : Atlas Copco F9C-11	3/09/2013	Inspect/ check L track frame, shaft
DRG003 : Atlas Copco F9C-11	3/09/2013	Make side hammer & remove
DRG003 : Atlas Copco F9C-11	3/09/2013	Parts
DRG003 : Atlas Copco F9C-11	4/09/2013	Assist remove radiator & inspect radiator
DRG003 : Atlas Copco F9C-11	4/09/2013	Parts
DRG003 : Atlas Copco F9C-11	4/09/2013	Remove radiator & cooler
DRG003 : Atlas Copco F9C-11	5/09/2013	Follow up parts list/ get radiator repairs under w
DRG003 : Atlas Copco F9C-11	5/09/2013	Parts
DRG003 : Atlas Copco F9C-11	6/09/2013	Help remove drifter
DRG003 : Atlas Copco F9C-11	6/09/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	9/09/2013	Parts
DRG003 : Atlas Copco F9C-11	10/09/2013	Parts

DRG003 : Atlas Copco F9C-11	10/09/2013	Parts
DRG003 : Atlas Copco F9C-11	13/09/2013	Parts
DRG003 : Atlas Copco F9C-11	14/09/2013	Gas low side & high side rock drill
DRG003 : Atlas Copco F9C-11	15/09/2013	Adjust top rod handler stops to improve thread
DRG003 : Atlas Copco F9C-11	16/09/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	17/09/2013	Walk drill up to north dump rod for fueling
DRG003 : Atlas Copco F9C-11	18/09/2013	Attend drill with supervisor, to assist diagnose d
DRG003 : Atlas Copco F9C-11	18/09/2013	Check for carousel not functioning
DRG003 : Atlas Copco F9C-11	18/09/2013	Parts
DRG003 : Atlas Copco F9C-11	19/09/2013	Adjust carousel
DRG003 : Atlas Copco F9C-11	19/09/2013	Parts
DRG003 : Atlas Copco F9C-11	19/09/2013	Parts
DRG003 : Atlas Copco F9C-11	19/09/2013	Parts
DRG003 : Atlas Copco F9C-11	21/09/2013	Service
DRG003 : Atlas Copco F9C-11	22/09/2013	250 hr service/ diagnose and rectify a/c not work
DRG003 : Atlas Copco F9C-11	22/09/2013	250 hr service/ repair grease leak/ repair jaw pin
DRG003 : Atlas Copco F9C-11	24/09/2013	Check Batteries, charge rate, earths & ignition
DRG003 : Atlas Copco F9C-11	24/09/2013	Go to town to pick up parts
DRG003 : Atlas Copco F9C-11	25/09/2013	Check accumulator pressures. Remove blown ho:
DRG003 : Atlas Copco F9C-11	26/09/2013	Charge accumulators
DRG003 : Atlas Copco F9C-11	29/09/2013	Hydraulic leak replair
DRG003 : Atlas Copco F9C-11	30/09/2013	Repair wiring & clean tracks out
DRG003 : Atlas Copco F9C-11	30/09/2013	Service
DRG003 : Atlas Copco F9C-11	2/10/2013	Replaced rubber at bottom of boom
DRG003 : Atlas Copco F9C-11	3/10/2013	Adjust tracks, repaired starting problem
DRG003 : Atlas Copco F9C-11	6/10/2013	A/C innop, check power to both condensor fans,
DRG003 : Atlas Copco F9C-11	7/10/2013	Check over fault list
DRG003 : Atlas Copco F9C-11	8/10/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	8/10/2013	Parts
DRG003 : Atlas Copco F9C-11	8/10/2013	Parts
DRG003 : Atlas Copco F9C-11	8/10/2013	Parts
DRG003 : Atlas Copco F9C-11	8/10/2013	Parts
DRG003 : Atlas Copco F9C-11	9/10/2013	Inspect modules & hoses, draw
DRG003 : Atlas Copco F9C-11	9/10/2013	Parts
DRG003 : Atlas Copco F9C-11	11/10/2013	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	12/10/2013	Rebuild drifter dampaner replace A/C
DRG003 : Atlas Copco F9C-11	14/10/2013	Parts
DRG003 : Atlas Copco F9C-11	14/10/2013	Parts
DRG003 : Atlas Copco F9C-11	15/10/2013	Parts
DRG003 : Atlas Copco F9C-11	15/10/2013	Parts
DRG003 : Atlas Copco F9C-11	21/10/2013	Parts
DRG003 : Atlas Copco F9C-11	27/10/2013	Parts
DRG003 : Atlas Copco F9C-11	2/11/2013	Inspect drill/ hoses/ rod handler
DRG003 : Atlas Copco F9C-11	3/11/2013	Remove blown hose make & fit new hose
DRG003 : Atlas Copco F9C-11	4/11/2013	Call out
DRG003 : Atlas Copco F9C-11	4/11/2013	Parts
DRG003 : Atlas Copco F9C-11	4/11/2013	Parts
DRG003 : Atlas Copco F9C-11	4/11/2013	Parts
DRG003 : Atlas Copco F9C-11	6/11/2013	Pressure testing on hyd system & check rod hanc
DRG003 : Atlas Copco F9C-11	7/11/2013	Assist brain with fitting new reel down

DRG003 : Atlas Copco F9C-11	7/11/2013	Replace reseak drum replaced reel hoses
DRG003 : Atlas Copco F9C-11	7/11/2013	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	8/11/2013	Repair grease system tidy up hoses
DRG003 : Atlas Copco F9C-11	9/11/2013	Inspect minor leaks
DRG003 : Atlas Copco F9C-11	16/11/2013	Tighten fitting on drifter/ rock drill
DRG003 : Atlas Copco F9C-11	18/11/2013	Parts
DRG003 : Atlas Copco F9C-11	18/11/2013	Sort out filter kit, clean down ready for service
DRG003 : Atlas Copco F9C-11	19/11/2013	Carry out 500 hr service
DRG003 : Atlas Copco F9C-11	20/11/2013	Change main pump drive
DRG003 : Atlas Copco F9C-11	20/11/2013	Parts
DRG003 : Atlas Copco F9C-11	21/11/2013	Finish asumble at pump drive, refit steps over pu
DRG003 : Atlas Copco F9C-11	25/11/2013	Refit rubber boot on dust extraction
DRG003 : Atlas Copco F9C-11	26/11/2013	Repair canbus fault adjust drifter chain
DRG003 : Atlas Copco F9C-11	27/11/2013	Assist brain spartk with diagnosis of electrical f
DRG003 : Atlas Copco F9C-11	27/11/2013	Cleaned cable plugs, replaced isolators
DRG003 : Atlas Copco F9C-11	27/11/2013	Parts
DRG003 : Atlas Copco F9C-11	27/11/2013	Parts
DRG003 : Atlas Copco F9C-11	28/11/2013	Parts
DRG003 : Atlas Copco F9C-11	28/11/2013	Parts
DRG003 : Atlas Copco F9C-11	28/11/2013	Small repairs & order parts
DRG003 : Atlas Copco F9C-11	29/11/2013	Change compessor oil
DRG003 : Atlas Copco F9C-11	29/11/2013	Parts
DRG003 : Atlas Copco F9C-11	30/11/2013	Replaced can cables
DRG003 : Atlas Copco F9C-11	1/12/2013	Breakdown
DRG003 : Atlas Copco F9C-11	2/12/2013	Breakdowns
DRG003 : Atlas Copco F9C-11	2/12/2013	Workshop Tools
DRG003 : Atlas Copco F9C-11	5/12/2013	Parts
DRG003 : Atlas Copco F9C-11	5/12/2013	Parts
DRG003 : Atlas Copco F9C-11	10/12/2013	Parts
DRG003 : Atlas Copco F9C-11	10/12/2013	Sort out problems with rod handler, text
DRG003 : Atlas Copco F9C-11	11/12/2013	Parts
DRG003 : Atlas Copco F9C-11	11/12/2013	Sort out problem with tracks
DRG003 : Atlas Copco F9C-11	13/12/2013	Order parts
DRG003 : Atlas Copco F9C-11	14/12/2013	Grind fabricate & weld plate into sampling chute
DRG003 : Atlas Copco F9C-11	17/12/2013	Parts
DRG003 : Atlas Copco F9C-11	19/12/2013	Parts
DRG003 : Atlas Copco F9C-11	23/12/2013	Parts
DRG003 : Atlas Copco F9C-11	23/12/2013	Parts
DRG003 : Atlas Copco F9C-11	24/12/2013	Parts
DRG003 : Atlas Copco F9C-11	26/12/2013	C/O hose/ diagnose leak
DRG003 : Atlas Copco F9C-11	28/12/2013	Make bracket for cyclone shoot
DRG003 : Atlas Copco F9C-11	28/12/2013	Rectify post repairs, non-control of can-bus
DRG003 : Atlas Copco F9C-11	5/01/2014	Sort out problem with broken shaft
DRG003 : Atlas Copco F9C-11	6/01/2014	Remove drifter fit new one & completetion of 10
DRG003 : Atlas Copco F9C-11	7/01/2014	Test, replace low side accumulator dietam
DRG003 : Atlas Copco F9C-11	8/01/2014	Charge accumulators with nitrogen
DRG003 : Atlas Copco F9C-11	8/01/2014	Drive to Cobar, deliver accumulator
DRG003 : Atlas Copco F9C-11	8/01/2014	Parts
DRG003 : Atlas Copco F9C-11	8/01/2014	Parts
DRG003 : Atlas Copco F9C-11	11/01/2014	Bushes & jaws
DRG003 : Atlas Copco F9C-11	12/01/2014	Change adjuster bolts on jaws

DRG003 : Atlas Copco F9C-11	12/01/2014	Replace jaws
DRG003 : Atlas Copco F9C-11	13/01/2014	Check on con system
DRG003 : Atlas Copco F9C-11	14/01/2014	Can bus fault
DRG003 : Atlas Copco F9C-11	14/01/2014	Replace module fault
DRG003 : Atlas Copco F9C-11	15/01/2014	Can bus problems
DRG003 : Atlas Copco F9C-11	15/01/2014	Find fault at 10 module
DRG003 : Atlas Copco F9C-11	15/01/2014	Parts
DRG003 : Atlas Copco F9C-11	15/01/2014	Parts
DRG003 : Atlas Copco F9C-11	16/01/2014	Can bus problems
DRG003 : Atlas Copco F9C-11	17/01/2014	Reet module can
DRG003 : Atlas Copco F9C-11	21/01/2014	Re attach fire supression to rear of drill rig
DRG003 : Atlas Copco F9C-11	22/01/2014	Workshop Tools
DRG003 : Atlas Copco F9C-11	25/01/2014	Fit parts so that drill can be used
DRG003 : Atlas Copco F9C-11	25/01/2014	Sort out problem, drifter not hammering
DRG003 : Atlas Copco F9C-11	26/01/2014	Sort out problem with wate
DRG003 : Atlas Copco F9C-11	28/01/2014	Parts
DRG003 : Atlas Copco F9C-11	28/01/2014	Parts
DRG003 : Atlas Copco F9C-11	28/01/2014	Remove roof lining, seal up air box
DRG003 : Atlas Copco F9C-11	29/01/2014	Fit panel, start, reassemble cab try to start sort
DRG003 : Atlas Copco F9C-11	29/01/2014	Freight
DRG003 : Atlas Copco F9C-11	29/01/2014	Parts
DRG003 : Atlas Copco F9C-11	29/01/2014	Parts
DRG003 : Atlas Copco F9C-11	29/01/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	30/01/2014	Hekp stlas copco machanic sort out problem
DRG003 : Atlas Copco F9C-11	31/01/2014	Freight
DRG003 : Atlas Copco F9C-11	5/02/2014	Rock drill replacment & electric faults
DRG003 : Atlas Copco F9C-11	6/02/2014	Broken shank
DRG003 : Atlas Copco F9C-11	6/02/2014	Repairs
DRG003 : Atlas Copco F9C-11	7/02/2014	Completion at 10 hr break
DRG003 : Atlas Copco F9C-11	7/02/2014	Tightended break down
DRG003 : Atlas Copco F9C-11	8/02/2014	Check rod
DRG003 : Atlas Copco F9C-11	8/02/2014	Completion of 10hr brake
DRG003 : Atlas Copco F9C-11	8/02/2014	Sort out tools
DRG003 : Atlas Copco F9C-11	9/02/2014	Check water in roat
DRG003 : Atlas Copco F9C-11	9/02/2014	Find water leak in roof dismantle & seal up
DRG003 : Atlas Copco F9C-11	10/02/2014	Check A/C operation
DRG003 : Atlas Copco F9C-11	11/02/2014	Parts
DRG003 : Atlas Copco F9C-11	11/02/2014	Parts
DRG003 : Atlas Copco F9C-11	13/02/2014	Check filters & camera
DRG003 : Atlas Copco F9C-11	14/02/2014	1000 hr service
DRG003 : Atlas Copco F9C-11	15/02/2014	Sort out starting problem
DRG003 : Atlas Copco F9C-11	17/02/2014	Parts
DRG003 : Atlas Copco F9C-11	17/02/2014	Service
DRG003 : Atlas Copco F9C-11	17/02/2014	Service
DRG003 : Atlas Copco F9C-11	18/02/2014	Freight
DRG003 : Atlas Copco F9C-11	18/02/2014	Parts
DRG003 : Atlas Copco F9C-11	18/02/2014	Service
DRG003 : Atlas Copco F9C-11	18/02/2014	Service & repairs
DRG003 : Atlas Copco F9C-11	19/02/2014	Repair & starting issues
DRG003 : Atlas Copco F9C-11	19/02/2014	Service
DRG003 : Atlas Copco F9C-11	19/02/2014	Sort outelectric al problem

DRG003 : Atlas Copco F9C-11	20/02/2014	Parts
DRG003 : Atlas Copco F9C-11	20/02/2014	Repairs
DRG003 : Atlas Copco F9C-11	21/02/2014	Repairs
DRG003 : Atlas Copco F9C-11	22/02/2014	172-172.2 issues, rod measure
DRG003 : Atlas Copco F9C-11	25/02/2014	Weld up hinge on cyclone
DRG003 : Atlas Copco F9C-11	27/02/2014	Parts
DRG003 : Atlas Copco F9C-11	27/02/2014	Repair oil leak
DRG003 : Atlas Copco F9C-11	3/03/2014	Parts
DRG003 : Atlas Copco F9C-11	3/03/2014	Tighten battery clamp
DRG003 : Atlas Copco F9C-11	4/03/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	4/03/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	7/03/2014	Parts
DRG003 : Atlas Copco F9C-11	7/03/2014	Replaced can cables, replaced grease tub
DRG003 : Atlas Copco F9C-11	8/03/2014	Elec testing faults
DRG003 : Atlas Copco F9C-11	8/03/2014	Try to find electrical fault
DRG003 : Atlas Copco F9C-11	9/03/2014	Reassemble cab
DRG003 : Atlas Copco F9C-11	10/03/2014	Parts
DRG003 : Atlas Copco F9C-11	10/03/2014	Replaced drill shanks
DRG003 : Atlas Copco F9C-11	11/03/2014	Parts
DRG003 : Atlas Copco F9C-11	13/03/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	18/03/2014	Look at electrical problem
DRG003 : Atlas Copco F9C-11	20/03/2014	Parts
DRG003 : Atlas Copco F9C-11	20/03/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	14/05/2014	Parts
DRG003 : Atlas Copco F9C-11	31/05/2014	Repair electrical fault
DRG003 : Atlas Copco F9C-11	10/06/2014	Relocate drill
DRG003 : Atlas Copco F9C-11	11/06/2014	Pulled off belly plates
DRG003 : Atlas Copco F9C-11	11/06/2014	Removed belly plates
DRG003 : Atlas Copco F9C-11	19/06/2014	Fit belly plates
DRG003 : Atlas Copco F9C-11	24/06/2014	Organise & inspect scope of work, removed rear
DRG003 : Atlas Copco F9C-11	25/06/2014	Christopher Joyce
DRG003 : Atlas Copco F9C-11	25/06/2014	Load on float
DRG003 : Atlas Copco F9C-11	25/06/2014	Straighten panel door, straighten sample chute
DRG003 : Atlas Copco F9C-11	26/06/2014	Christopher Joyce
DRG003 : Atlas Copco F9C-11	27/06/2014	Repair step
DRG003 : Atlas Copco F9C-11	30/06/2014	Blast & paint steps
DRG003 : Atlas Copco F9C-11	30/06/2014	Repair step
DRG003 : Atlas Copco F9C-11	2/07/2014	Tightend belts did front wheel bearings
DRG003 : Atlas Copco F9C-11	10/07/2014	Parts
DRG003 : Atlas Copco F9C-11	10/07/2014	Repairs to dust box
DRG003 : Atlas Copco F9C-11	8/08/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	2/09/2014	Replace rear step
DRG003 : Atlas Copco F9C-11	5/09/2014	Straighten belly plates
drg003 : Atlas Copco F9C-11	8/09/2014	Parts
DRG003 : Atlas Copco F9C-11	8/09/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	8/09/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	9/09/2014	Fabricate belly plates
DRG003 : Atlas Copco F9C-11	10/09/2014	Fabricate belly plates
DRG003 : Atlas Copco F9C-11	11/09/2014	Inspect hyd funsction faults has a comms issue
DRG003 : Atlas Copco F9C-11	11/09/2014	Make belly plates
DRG003 : Atlas Copco F9C-11	11/09/2014	Moved and tried to get controls to work properly

DRG003 : Atlas Copco F9C-11	12/09/2014	Assist atlas copco with drill fault
DRG003 : Atlas Copco F9C-11	15/09/2014	Paint parts
DRG003 : Atlas Copco F9C-11	15/09/2014	Tried to get to wash bay
DRG003 : Atlas Copco F9C-11	16/09/2014	Move drill up to wash bay area found fault
DRG003 : Atlas Copco F9C-11	16/09/2014	Paint panels
DRG003 : Atlas Copco F9C-11	17/09/2014	Put on wash bay
DRG003 : Atlas Copco F9C-11	19/09/2014	Move off wash bay, was VOC'D
DRG003 : Atlas Copco F9C-11	22/09/2014	Started unwrapping sprial wrap form boom hose
DRG003 : Atlas Copco F9C-11	23/09/2014	Remove hyd hoses to reclamp, re calibrate feede
DRG003 : Atlas Copco F9C-11	24/09/2014	Continue repairs, replacing hoses, resetting hose
DRG003 : Atlas Copco F9C-11	24/09/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	25/09/2014	Clean & refit battery terminals on both battery
DRG003 : Atlas Copco F9C-11	25/09/2014	Parts
DRG003 : Atlas Copco F9C-11	25/09/2014	Parts
DRG003 : Atlas Copco F9C-11	25/09/2014	Parts
DRG003 : Atlas Copco F9C-11	26/09/2014	Reclaimed rod handling system, reloaded all rods
DRG003 : Atlas Copco F9C-11	26/09/2014	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	29/09/2014	Check operation of auto greaser found several is:
DRG003 : Atlas Copco F9C-11	30/09/2014	Unload drill from truck, repairgrease line, test
DRG003 : Atlas Copco F9C-11	12/11/2014	Parts
DRG003 : Atlas Copco F9C-11	27/01/2015	Charge batteries & load test
DRG003 : Atlas Copco F9C-11	28/01/2015	Parts
DRG003 : Atlas Copco F9C-11	30/01/2015	Shift over creek, would not start
DRG003 : Atlas Copco F9C-11	30/01/2015	Unloaded from float, give mark rose run down
DRG003 : Atlas Copco F9C-11	2/02/2015	Move drill over creek
DRG003 : Atlas Copco F9C-11	3/02/2015	master switch
DRG003 : Atlas Copco F9C-11	4/02/2015	Modified computer battery holder to suit bigger
DRG003 : Atlas Copco F9C-11	5/02/2015	Replace & test isolator on drill rig
DRG003 : Atlas Copco F9C-11	6/02/2015	Diagnose no start fault
DRG003 : Atlas Copco F9C-11	11/02/2015	Continue CAN fault dial more tests required
DRG003 : Atlas Copco F9C-11	16/02/2015	Diagnose computer fault, contacted atlas
DRG003 : Atlas Copco F9C-11	6/03/2015	Completed diagnosis of C.A.N fault with atlas cop
DRG003 : Atlas Copco F9C-11	6/03/2015	Parts
DRG003 : Atlas Copco F9C-11	13/03/2015	Continue electrical repairs, fitted 2 new power
DRG003 : Atlas Copco F9C-11	13/03/2015	Service
DRG003 : Atlas Copco F9C-11	16/03/2015	Parts
DRG003 : Atlas Copco F9C-11	16/03/2015	Parts
DRG003 : Atlas Copco F9C-11	16/03/2015	Parts
DRG003 : Atlas Copco F9C-11	16/03/2015	Parts
DRG003 : Atlas Copco F9C-11	17/03/2015	Service & minor repairs cleaned coolers
DRG003 : Atlas Copco F9C-11	18/03/2015	Complete service paper work
DRG003 : Atlas Copco F9C-11	18/03/2015	supply 1 hyd hose
DRG003 : Atlas Copco F9C-11	30/03/2015	Repaired oil leak on compressor replaced gasket
DRG003 : Atlas Copco F9C-11	28/04/2015	Test and prep for Mt Isa load onto float
DRG003 : Atlas Copco F9C-11	29/04/2015	Parts
DRG003 : Atlas Copco F9C-11	29/04/2015	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	14/05/2015	3216719980 Band Pulley (Track Roller)
DRG003 : Atlas Copco F9C-11	28/05/2015	Check over starting issues test
DRG003 : Atlas Copco F9C-11	29/05/2015	Parts
DRG003 : Atlas Copco F9C-11	31/05/2015	Replace switch
DRG003 : Atlas Copco F9C-11	1/06/2015	Diagnosed electrical fault

DRG003 : Atlas Copco F9C-11	1/06/2015	Found broken sensor & removed, ordered new p
drg003 : Atlas Copco F9C-11	2/06/2015	Freight
DRG003 : Atlas Copco F9C-11	2/06/2015	Parts
DRG003 : Atlas Copco F9C-11	3/06/2015	Inspect start fault
DRG003 : Atlas Copco F9C-11	4/06/2015	Inspect start fault
DRG003 : Atlas Copco F9C-11	8/06/2015	Parts
DRG003 : Atlas Copco F9C-11	12/06/2015	Rect depth grease inap rect cyclone splittler inop
DRG003 : Atlas Copco F9C-11	12/06/2015	Repair head sensor fault,s eal up control boxes
DRG003 : Atlas Copco F9C-11	12/06/2015	Repairs/ watch
DRG003 : Atlas Copco F9C-11	13/06/2015	Check over, repairs and help prestart
DRG003 : Atlas Copco F9C-11	14/06/2015	A/C repairs
DRG003 : Atlas Copco F9C-11	14/06/2015	Check air con inap
DRG003 : Atlas Copco F9C-11	14/06/2015	Remove aircon comp, cable tie belt up and plug
DRG003 : Atlas Copco F9C-11	14/06/2015	Replace drigter shank
DRG003 : Atlas Copco F9C-11	15/06/2015	Change out compressor & dryer gas system
DRG003 : Atlas Copco F9C-11	15/06/2015	Replace air con compressor, flush & gas & check
DRG003 : Atlas Copco F9C-11	22/06/2015	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	22/06/2015	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	23/06/2015	Inspect track tensions, inspect chain tensions
DRG003 : Atlas Copco F9C-11	24/06/2015	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	25/06/2015	Parts
DRG003 : Atlas Copco F9C-11	26/06/2015	Parts
DRG003 : Atlas Copco F9C-11	26/06/2015	Parts
drg003 : Atlas Copco F9C-11	26/06/2015	Parts
DRG003 : Atlas Copco F9C-11	28/06/2015	500hr service
DRG003 : Atlas Copco F9C-11	30/06/2015	Parts
DRG003 : Atlas Copco F9C-11	30/06/2015	Parts
DRG003 : Atlas Copco F9C-11	5/07/2015	Change out rods
DRG003 : Atlas Copco F9C-11	6/07/2015	Parts
DRG003 : Atlas Copco F9C-11	9/07/2015	Airline
DRG003 : Atlas Copco F9C-11	12/07/2015	Replace jaws, repair dust ext
DRG003 : Atlas Copco F9C-11	13/07/2015	Inspect compressor oil cooler
DRG003 : Atlas Copco F9C-11	13/07/2015	Repair hyd leak
DRG003 : Atlas Copco F9C-11	15/07/2015	Inspect cooler leak
DRG003 : Atlas Copco F9C-11	27/07/2015	Parts
DRG003 : Atlas Copco F9C-11	29/07/2015	Service
DRG003 : Atlas Copco F9C-11	30/07/2015	Jump start
DRG003 : Atlas Copco F9C-11	4/08/2015	Make hose
DRG003 : Atlas Copco F9C-11	2/09/2015	Lift mast ect get in shed remove broken valve
DRG003 : Atlas Copco F9C-11	3/09/2015	0211122300 screw
DRG003 : Atlas Copco F9C-11	3/09/2015	3177309256 seal kit
DRG003 : Atlas Copco F9C-11	3/09/2015	3177309283 direction valve
DRG003 : Atlas Copco F9C-11	3/09/2015	3222326896 double change valve
DRG003 : Atlas Copco F9C-11	3/09/2015	3222330822 seal kit
DRG003 : Atlas Copco F9C-11	3/09/2015	Atlas copco
DRG003 : Atlas Copco F9C-11	3/09/2015	Fix valve drive off of float up to wash pad
DRG003 : Atlas Copco F9C-11	3/09/2015	make and fit hoses @ Darlington
DRG003 : Atlas Copco F9C-11	3/09/2015	Remove from flot hyd fault
DRG003 : Atlas Copco F9C-11	3/09/2015	Replased hoses put new valve on unloaded
DRG003 : Atlas Copco F9C-11	7/09/2015	Bring down from wash bay
DRG003 : Atlas Copco F9C-11	7/09/2015	Bring down from washbay, start removing valve

DRG003 : Atlas Copco F9C-11	8/09/2015	Finish off remving valve bank mounting
DRG003 : Atlas Copco F9C-11	8/09/2015	Pulled hoses and wiring off to take bemt plate of
DRG003 : Atlas Copco F9C-11	10/09/2015	Repairs and maintenace to drill rig
DRG003 : Atlas Copco F9C-11	11/09/2015	Fabricate valve blovk cover
DRG003 : Atlas Copco F9C-11	11/09/2015	Parts
DRG003 : Atlas Copco F9C-11	11/09/2015	Prep and paint panels
DRG003 : Atlas Copco F9C-11	14/09/2015	Finish paint panels
DRG003 : Atlas Copco F9C-11	16/09/2015	Remove drill rid from workshop
DRG003 : Atlas Copco F9C-11	17/09/2015	Begin valve body install
DRG003 : Atlas Copco F9C-11	18/09/2015	120cm straps
DRG003 : Atlas Copco F9C-11	18/09/2015	50cm straps
DRG003 : Atlas Copco F9C-11	18/09/2015	Install hyd valve after damage
DRG003 : Atlas Copco F9C-11	18/09/2015	Put hyd and electrical cables back on
DRG003 : Atlas Copco F9C-11	23/09/2015	Put dirt bucket on, concreted hyd and electrical
DRG003 : Atlas Copco F9C-11	23/09/2015	Signage
DRG003 : Atlas Copco F9C-11	23/09/2015	Wiring from transport damage
DRG003 : Atlas Copco F9C-11	24/09/2015	Finish off damage repair and remove radiator cha
DRG003 : Atlas Copco F9C-11	24/09/2015	Pulled out radiator, pulled apart radiator from
DRG003 : Atlas Copco F9C-11	25/09/2015	Pulled out others radiator pulled a part pressure
DRG003 : Atlas Copco F9C-11	25/09/2015	Remove oil coolers to fan support
DRG003 : Atlas Copco F9C-11	28/09/2015	Cut parts for fan mount
DRG003 : Atlas Copco F9C-11	29/09/2015	make 5 hoses inv 56002/5
DRG003 : Atlas Copco F9C-11	29/09/2015	Radiator and oil cooler
DRG003 : Atlas Copco F9C-11	29/09/2015	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	30/09/2015	3222.3084.32 dampner
DRG003 : Atlas Copco F9C-11	30/09/2015	Radiator assembly
DRG003 : Atlas Copco F9C-11	1/10/2015	Radiator and oil cooler repairs
DRG003 : Atlas Copco F9C-11	1/10/2015	Repair and weld fan holder
DRG003 : Atlas Copco F9C-11	2/10/2015	Assemble coolers
DRG003 : Atlas Copco F9C-11	2/10/2015	Parts
DRG003 : Atlas Copco F9C-11	2/10/2015	Put together oil cooler assembly
DRG003 : Atlas Copco F9C-11	2/10/2015	seals
DRG003 : Atlas Copco F9C-11	6/10/2015	final drive o rings
DRG003 : Atlas Copco F9C-11	6/10/2015	Install coolers
DRG003 : Atlas Copco F9C-11	6/10/2015	Oil coolers install and radiator install
DRG003 : Atlas Copco F9C-11	7/10/2015	final drive o rings
DRG003 : Atlas Copco F9C-11	7/10/2015	Install coolers and assemble final drive s
DRG003 : Atlas Copco F9C-11	7/10/2015	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	7/10/2015	Radaitor install and computer fault finding
DRG003 : Atlas Copco F9C-11	7/10/2015	supply and fit 1 hose inv 56009/5
DRG003 : Atlas Copco F9C-11	8/10/2015	Check for leaks when running put rod in
DRG003 : Atlas Copco F9C-11	8/10/2015	Run machine top up oil checked charge charge ac
DRG003 : Atlas Copco F9C-11	9/10/2015	Adjust feed chain put rods in adjust hose reel sid
DRG003 : Atlas Copco F9C-11	9/10/2015	Put rods in adjusted chains
DRG003 : Atlas Copco F9C-11	12/10/2015	Test drill machine with operator
DRG003 : Atlas Copco F9C-11	26/10/2015	Sticker
DRG003 : Atlas Copco F9C-11	5/11/2015	9106 1704 62 electronic unit
DRG003 : Atlas Copco F9C-11	5/11/2015	Find faulty length sensor card, full of water
DRG003 : Atlas Copco F9C-11	6/11/2015	Travel to and from, fit new circuit board to boom
DRG003 : Atlas Copco F9C-11	11/11/2015	Inspect fault on rod handling
DRG003 : Atlas Copco F9C-11	13/11/2015	repair hyd hoses at hind valley

DRG003 : Atlas Copco F9C-11	17/11/2015	Complete repairs, recharge low pressure accumu
DRG003 : Atlas Copco F9C-11	18/11/2015	repair accumulator
DRG003 : Atlas Copco F9C-11	2/12/2015	Travel to hindmarsh valley to load drill onto floa
DRG003 : Atlas Copco F9C-11	10/12/2015	0324155161 backup ring
DRG003 : Atlas Copco F9C-11	10/12/2015	0335122600 circlip
DRG003 : Atlas Copco F9C-11	10/12/2015	3214575000 brg
DRG003 : Atlas Copco F9C-11	10/12/2015	Freight
DRG003 : Atlas Copco F9C-11	10/12/2015	Lock at broken stick pin tram down
DRG003 : Atlas Copco F9C-11	10/12/2015	Mast pin broken
DRG003 : Atlas Copco F9C-11	11/12/2015	3222306401 shaft
DRG003 : Atlas Copco F9C-11	11/12/2015	Move into workshop after putting pin back in
DRG003 : Atlas Copco F9C-11	11/12/2015	Relocate to shed for repairs
DRG003 : Atlas Copco F9C-11	12/12/2015	Remove pin clean up holes, remove and get hose
DRG003 : Atlas Copco F9C-11	12/12/2015	Repair bent brackets
DRG003 : Atlas Copco F9C-11	14/12/2015	Boom pin replace
DRG003 : Atlas Copco F9C-11	14/12/2015	Install boom pin and dive pitside
DRG003 : Atlas Copco F9C-11	16/12/2015	refurbish boom lift pin bore
DRG003 : Atlas Copco F9C-11	23/12/2015	Load/ unload drill rig
DRG003 : Atlas Copco F9C-11	6/01/2016	Unload from trailer, remove drifter & clean
DRG003 : Atlas Copco F9C-11	7/01/2016	Repairs & assment
DRG003 : Atlas Copco F9C-11	11/01/2016	Parts for drifter slide
DRG003 : Atlas Copco F9C-11	11/01/2016	Parts for drifter slide
DRG003 : Atlas Copco F9C-11	11/01/2016	Parts for drifter slide
DRG003 : Atlas Copco F9C-11	11/01/2016	Repairs to hoses & hose brackets
DRG003 : Atlas Copco F9C-11	12/01/2016	Continued repairs, hoses & hose brackets
DRG003 : Atlas Copco F9C-11	12/01/2016	repair hoses
DRG003 : Atlas Copco F9C-11	13/01/2016	Repairs & maintenace
DRG003 : Atlas Copco F9C-11	15/01/2016	Craddle repairs, refit
DRG003 : Atlas Copco F9C-11	15/01/2016	Put runner on and set up
DRG003 : Atlas Copco F9C-11	18/01/2016	3222315343 sliding piece
DRG003 : Atlas Copco F9C-11	18/01/2016	Craddle & reel repairs
DRG003 : Atlas Copco F9C-11	22/01/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	25/01/2016	Repairs & maint reel sticks
DRG003 : Atlas Copco F9C-11	2/02/2016	Repairs/maintenace
DRG003 : Atlas Copco F9C-11	4/02/2016	Put drifter on
DRG003 : Atlas Copco F9C-11	4/02/2016	Refitted drifte, replaced dust, boot gasket
DRG003 : Atlas Copco F9C-11	5/02/2016	Sticker & clean
DRG003 : Atlas Copco F9C-11	5/02/2016	Wash rig
DRG003 : Atlas Copco F9C-11	8/02/2016	Inspect/ repair order parts/ fot auto greaser
DRG003 : Atlas Copco F9C-11	9/02/2016	Sticker R&R
DRG003 : Atlas Copco F9C-11	10/02/2016	Compressor filter
DRG003 : Atlas Copco F9C-11	10/02/2016	Hydraulic Return Filters
DRG003 : Atlas Copco F9C-11	10/02/2016	Hydraulic Return Filters
DRG003 : Atlas Copco F9C-11	11/02/2016	auto greaser parts
DRG003 : Atlas Copco F9C-11	11/02/2016	HF35315 Hydraulic Filters
DRG003 : Atlas Copco F9C-11	11/02/2016	Repaired auto greaser- fitted new elements
DRG003 : Atlas Copco F9C-11	16/02/2016	Completed service & repairs , tick sheet
DRG003 : Atlas Copco F9C-11	16/02/2016	service drifter from F9 -
DRG003 : Atlas Copco F9C-11	26/02/2016	Check operation of dust extractor
DRG003 : Atlas Copco F9C-11	29/02/2016	3222318922 filter
DRG003 : Atlas Copco F9C-11	29/02/2016	clamps

DRG003 : Atlas Copco F9C-11	29/02/2016	Inspect dust extraction system, clean dust
DRG003 : Atlas Copco F9C-11	29/02/2016	Pick up filter from atlas copco
DRG003 : Atlas Copco F9C-11	29/02/2016	Replace larce, dust suction hose, repair latches
DRG003 : Atlas Copco F9C-11	29/02/2016	suction hose
DRG003 : Atlas Copco F9C-11	1/03/2016	3222302492 kit
DRG003 : Atlas Copco F9C-11	1/03/2016	Starting issue on float
DRG003 : Atlas Copco F9C-11	2/03/2016	Start on float
DRG003 : Atlas Copco F9C-11	7/03/2016	Broken fitting on drill grab cylinder, remove
DRG003 : Atlas Copco F9C-11	7/03/2016	Mast E-Stop fault
DRG003 : Atlas Copco F9C-11	10/03/2016	Inspect hyd oil leak, found faulty hose
DRG003 : Atlas Copco F9C-11	11/03/2016	Daniel Cowled
DRG003 : Atlas Copco F9C-11	15/03/2016	Daniel Cowled
DRG003 : Atlas Copco F9C-11	15/03/2016	Diagnose electrical fault
DRG003 : Atlas Copco F9C-11	15/03/2016	Investogate electrical fault
DRG003 : Atlas Copco F9C-11	15/03/2016	Parts
DRG003 : Atlas Copco F9C-11	16/03/2016	Diagnose starting fault
DRG003 : Atlas Copco F9C-11	16/03/2016	Investigate electrical issue
DRG003 : Atlas Copco F9C-11	17/03/2016	Investogate electrical fault
DRG003 : Atlas Copco F9C-11	21/03/2016	Put hoses back on shelves
DRG003 : Atlas Copco F9C-11	22/03/2016	Investogate electrical issues
DRG003 : Atlas Copco F9C-11	23/03/2016	Change hyd hose
DRG003 : Atlas Copco F9C-11	24/03/2016	Diagnose electrical fault, test wiring looms
DRG003 : Atlas Copco F9C-11	25/03/2016	Diagnose electrical fault with machine, found
DRG003 : Atlas Copco F9C-11	26/03/2016	Parts
DRG003 : Atlas Copco F9C-11	2/04/2016	Replace broken bolts due to rod not getting bogg
DRG003 : Atlas Copco F9C-11	5/04/2016	Chase up parts to get this machine of & rewiring
DRG003 : Atlas Copco F9C-11	6/04/2016	Parts
DRG003 : Atlas Copco F9C-11	7/04/2016	Changed out APP module replaced worn wiring
DRG003 : Atlas Copco F9C-11	7/04/2016	Weld repairs
DRG003 : Atlas Copco F9C-11	8/04/2016	Electrical issues
DRG003 : Atlas Copco F9C-11	8/04/2016	Try fault find 10 module fault
DRG003 : Atlas Copco F9C-11	9/04/2016	Eelctrical fault
DRG003 : Atlas Copco F9C-11	10/04/2016	Electrical issues
DRG003 : Atlas Copco F9C-11	11/04/2016	Electrical fault
DRG003 : Atlas Copco F9C-11	14/04/2016	Assist put nose onto hose drum
DRG003 : Atlas Copco F9C-11	14/04/2016	Put hose back on hose drum
DRG003 : Atlas Copco F9C-11	14/04/2016	Refit hose over hose reel
DRG003 : Atlas Copco F9C-11	15/04/2016	Carry out parts ordering for service
DRG003 : Atlas Copco F9C-11	15/04/2016	Grease & tidy up hoses over hose reel, adjust hos
DRG003 : Atlas Copco F9C-11	15/04/2016	Reposition most hoses
DRG003 : Atlas Copco F9C-11	16/04/2016	Hyd oil leak on top hammer, locate oil leak
DRG003 : Atlas Copco F9C-11	17/04/2016	Locate hyd oil leak, found loose fitting under cab
DRG003 : Atlas Copco F9C-11	19/04/2016	Carry out replacment of hyd hose
DRG003 : Atlas Copco F9C-11	19/04/2016	Hesater not working
DRG003 : Atlas Copco F9C-11	19/04/2016	Parts
DRG003 : Atlas Copco F9C-11	20/04/2016	Carousel alignment ECL low/hugh faulta
DRG003 : Atlas Copco F9C-11	20/04/2016	Freight
DRG003 : Atlas Copco F9C-11	21/04/2016	Assist atlas with module fault -found calbe rub th
DRG003 : Atlas Copco F9C-11	21/04/2016	Attach ECL cables & test o.k
DRG003 : Atlas Copco F9C-11	21/04/2016	Continue with fault diagnosing drill not function
DRG003 : Atlas Copco F9C-11	21/04/2016	Fit new A/C belt, fix door handle

DRG003 : Atlas Copco F9C-11	22/04/2016	Heater check & found seized heater valve remov
DRG003 : Atlas Copco F9C-11	23/04/2016	Adjust drill parameters & drill training
DRG003 : Atlas Copco F9C-11	24/04/2016	Replace rear D/C sock, cut & join
drg003 : Atlas Copco F9C-11	26/04/2016	Air Cleaners
drg003 : Atlas Copco F9C-11	26/04/2016	Service kit
DRG003 : Atlas Copco F9C-11	27/04/2016	Parts
DRG003 : Atlas Copco F9C-11	28/04/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	29/04/2016	Replace blown hose
DRG003 : Atlas Copco F9C-11	29/04/2016	Replace hose
DRG003 : Atlas Copco F9C-11	30/04/2016	250hr service
DRG003 : Atlas Copco F9C-11	30/04/2016	250hr service
DRG003 : Atlas Copco F9C-11	30/04/2016	Drive to broken hill pick up parts & return to sit
DRG003 : Atlas Copco F9C-11	30/04/2016	Filter cross ref, replace feed pressure switch
DRG003 : Atlas Copco F9C-11	2/05/2016	Organise parts
DRG003 : Atlas Copco F9C-11	2/05/2016	Parts
DRG003 : Atlas Copco F9C-11	4/05/2016	Assist with replace bearing bottom chair sproket
DRG003 : Atlas Copco F9C-11	4/05/2016	Failed bottom sprocket bearing
DRG003 : Atlas Copco F9C-11	4/05/2016	Parts
DRG003 : Atlas Copco F9C-11	7/05/2016	Blown hyd
DRG003 : Atlas Copco F9C-11	7/05/2016	Blown most hose
DRG003 : Atlas Copco F9C-11	7/05/2016	Mast hose remove
DRG003 : Atlas Copco F9C-11	9/05/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	9/05/2016	Refit new most hose
DRG003 : Atlas Copco F9C-11	9/05/2016	Replace mast hose
DRG003 : Atlas Copco F9C-11	10/05/2016	Parts
DRG003 : Atlas Copco F9C-11	14/05/2016	Sort out service kit & paperwork
DRG003 : Atlas Copco F9C-11	15/05/2016	Hyd leak on rotational head
DRG003 : Atlas Copco F9C-11	16/05/2016	Parts
DRG003 : Atlas Copco F9C-11	17/05/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	17/05/2016	Replace hose drill out broken bolts
DRG003 : Atlas Copco F9C-11	17/05/2016	Replace hyd hose leaks, fix broken bolt
DRG003 : Atlas Copco F9C-11	18/05/2016	Parts
DRG003 : Atlas Copco F9C-11	18/05/2016	Parts
DRG003 : Atlas Copco F9C-11	19/05/2016	500Hr Service Kit
DRG003 : Atlas Copco F9C-11	19/05/2016	Parts
DRG003 : Atlas Copco F9C-11	19/05/2016	Repair oil leak
DRG003 : Atlas Copco F9C-11	20/05/2016	Sampler not working
DRG003 : Atlas Copco F9C-11	20/05/2016	Splitter and valve faults
DRG003 : Atlas Copco F9C-11	21/05/2016	Replumb splitter valving
DRG003 : Atlas Copco F9C-11	21/05/2016	Sampler air system
DRG003 : Atlas Copco F9C-11	22/05/2016	Freight
DRG003 : Atlas Copco F9C-11	22/05/2016	Repair blown hose refit & drill
DRG003 : Atlas Copco F9C-11	23/05/2016	Parts
DRG003 : Atlas Copco F9C-11	23/05/2016	Parts
DRG003 : Atlas Copco F9C-11	24/05/2016	500hr service & repair faults drill out broken bol
DRG003 : Atlas Copco F9C-11	24/05/2016	Assist with service & repairs
DRG003 : Atlas Copco F9C-11	24/05/2016	Carry out 500hr service & defects
DRG003 : Atlas Copco F9C-11	24/05/2016	Carry out servie & defects
DRG003 : Atlas Copco F9C-11	25/05/2016	Assist to prime fuel & start machine
DRG003 : Atlas Copco F9C-11	25/05/2016	Fill with fuel & bleed
DRG003 : Atlas Copco F9C-11	25/05/2016	Oil & Lubricants

DRG003 : Atlas Copco F9C-11	25/05/2016	Parts
DRG003 : Atlas Copco F9C-11	25/05/2016	Parts
DRG003 : Atlas Copco F9C-11	26/05/2016	Repair eng oil leaks, install 6" suction hose
DRG003 : Atlas Copco F9C-11	26/05/2016	Repair oil leaks & fit sample hose
DRG003 : Atlas Copco F9C-11	26/05/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	27/05/2016	Investigate & repair oil leak, investigate electri
DRG003 : Atlas Copco F9C-11	27/05/2016	Organise labour to come to site to diagnose
DRG003 : Atlas Copco F9C-11	28/05/2016	Investigate electrical fault with Atlas service ma
DRG003 : Atlas Copco F9C-11	29/05/2016	Remove temo battery installation
DRG003 : Atlas Copco F9C-11	30/05/2016	Batteries
DRG003 : Atlas Copco F9C-11	30/05/2016	Fit batteries
DRG003 : Atlas Copco F9C-11	30/05/2016	Parts
DRG003 : Atlas Copco F9C-11	1/06/2016	Parts
DRG003 : Atlas Copco F9C-11	1/06/2016	Parts
DRG003 : Atlas Copco F9C-11	1/06/2016	Replace purge valves
DRG003 : Atlas Copco F9C-11	2/06/2016	Find numbers on hose pump
DRG003 : Atlas Copco F9C-11	2/06/2016	Fit on try to break out on site
DRG003 : Atlas Copco F9C-11	2/06/2016	Remove accumulators take to town for Draphran
DRG003 : Atlas Copco F9C-11	2/06/2016	Remove huey lines to repair leak out back togeth
DRG003 : Atlas Copco F9C-11	3/06/2016	Assist with HEVI pump install
DRG003 : Atlas Copco F9C-11	3/06/2016	Remove hue pumo & replace with new, top com
DRG003 : Atlas Copco F9C-11	4/06/2016	Change out faulty 2 way & hot seat
DRG003 : Atlas Copco F9C-11	4/06/2016	Repair interior cab light
DRG003 : Atlas Copco F9C-11	5/06/2016	Look at heater fan fault, look at interior light
DRG003 : Atlas Copco F9C-11	6/06/2016	Clino fault with atlas copco
DRG003 : Atlas Copco F9C-11	6/06/2016	Remove faulty cab interior light look at heater
DRG003 : Atlas Copco F9C-11	7/06/2016	Clino fault
DRG003 : Atlas Copco F9C-11	7/06/2016	Jump start
DRG003 : Atlas Copco F9C-11	8/06/2016	Parts
DRG003 : Atlas Copco F9C-11	9/06/2016	Wash rug & go over inspect for repairs & carry ou
DRG003 : Atlas Copco F9C-11	10/06/2016	Continue with maintenace
DRG003 : Atlas Copco F9C-11	10/06/2016	Parts
DRG003 : Atlas Copco F9C-11	10/06/2016	Seal up regulars & adjust pressures to Atlas spec
DRG003 : Atlas Copco F9C-11	11/06/2016	Change out heater control valve
DRG003 : Atlas Copco F9C-11	12/06/2016	Rekit d/l reg with new kit replace bearings on bot
DRG003 : Atlas Copco F9C-11	13/06/2016	Parts
DRG003 : Atlas Copco F9C-11	13/06/2016	Warm up/tram drills out of dump area
DRG003 : Atlas Copco F9C-11	14/06/2016	Parts
DRG003 : Atlas Copco F9C-11	15/06/2016	Parts
DRG003 : Atlas Copco F9C-11	17/06/2016	Check coolant leak
DRG003 : Atlas Copco F9C-11	17/06/2016	Coolant leak
DRG003 : Atlas Copco F9C-11	17/06/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	17/06/2016	Investogate & repair coolant leak
DRG003 : Atlas Copco F9C-11	20/06/2016	Parts
DRG003 : Atlas Copco F9C-11	21/06/2016	Call out to reapir blown hammer hose
DRG003 : Atlas Copco F9C-11	21/06/2016	Parts
DRG003 : Atlas Copco F9C-11	21/06/2016	Repair rod jaws
DRG003 : Atlas Copco F9C-11	22/06/2016	Back to work inspection on drill
DRG003 : Atlas Copco F9C-11	22/06/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	22/06/2016	Paper work, order parts etc
DRG003 : Atlas Copco F9C-11	23/06/2016	Parts

DRG003 : Atlas Copco F9C-11	24/06/2016	Core Return
DRG003 : Atlas Copco F9C-11	24/06/2016	Parts
DRG003 : Atlas Copco F9C-11	24/06/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	26/06/2016	Carry out 250hr service
DRG003 : Atlas Copco F9C-11	28/06/2016	Carry out replacment of drill shank
DRG003 : Atlas Copco F9C-11	28/06/2016	Replace drill shank
DRG003 : Atlas Copco F9C-11	29/06/2016	Drill repairs and diagnose fault
DRG003 : Atlas Copco F9C-11	30/06/2016	Parts
DRG003 : Atlas Copco F9C-11	30/06/2016	Remove drifter & organise repairs
DRG003 : Atlas Copco F9C-11	30/06/2016	Remove drifter off
DRG003 : Atlas Copco F9C-11	1/07/2016	Drill repairs
DRG003 : Atlas Copco F9C-11	1/07/2016	Fit drifter
DRG003 : Atlas Copco F9C-11	1/07/2016	Parts
DRG003 : Atlas Copco F9C-11	1/07/2016	Refit drifter
DRG003 : Atlas Copco F9C-11	2/07/2016	Adjust and replace rod arm jaws
DRG003 : Atlas Copco F9C-11	5/07/2016	Check pressures remove & build up gripper jaws
DRG003 : Atlas Copco F9C-11	5/07/2016	Parts
DRG003 : Atlas Copco F9C-11	6/07/2016	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	7/07/2016	Wash down drill rig so it can have repairs carried
DRG003 : Atlas Copco F9C-11	8/07/2016	Assist to remove drifter with IT Package
DRG003 : Atlas Copco F9C-11	8/07/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	12/07/2016	Maintenace
DRG003 : Atlas Copco F9C-11	13/07/2016	Assist to remove cylindewr
DRG003 : Atlas Copco F9C-11	13/07/2016	Carry out repairs
DRG003 : Atlas Copco F9C-11	13/07/2016	Freight
DRG003 : Atlas Copco F9C-11	13/07/2016	Parts
DRG003 : Atlas Copco F9C-11	13/07/2016	Parts
DRG003 : Atlas Copco F9C-11	13/07/2016	Parts
DRG003 : Atlas Copco F9C-11	13/07/2016	Parts
DRG003 : Atlas Copco F9C-11	13/07/2016	Remove boom cylinder
DRG003 : Atlas Copco F9C-11	13/07/2016	Remove cylinder
DRG003 : Atlas Copco F9C-11	14/07/2016	Assist to disassemble boom cylinder
DRG003 : Atlas Copco F9C-11	14/07/2016	Panel beat cyclone & splitter
DRG003 : Atlas Copco F9C-11	14/07/2016	Remove & disassemble boom lift cyl & order part
DRG003 : Atlas Copco F9C-11	15/07/2016	Carry out repairs, reg, bottom rod arm
DRG003 : Atlas Copco F9C-11	15/07/2016	Parts
DRG003 : Atlas Copco F9C-11	15/07/2016	Parts
DRG003 : Atlas Copco F9C-11	15/07/2016	Town run pick up parts
DRG003 : Atlas Copco F9C-11	16/07/2016	Drill repairs, top rod arms, tidy hoses & wiring
DRG003 : Atlas Copco F9C-11	16/07/2016	Repairs help
DRG003 : Atlas Copco F9C-11	16/07/2016	Tidy up drill container
DRG003 : Atlas Copco F9C-11	17/07/2016	Run to town pick up parts
DRG003 : Atlas Copco F9C-11	18/07/2016	Continue repairs
DRG003 : Atlas Copco F9C-11	18/07/2016	Remove dust pot
DRG003 : Atlas Copco F9C-11	19/07/2016	Assist drill repairs
DRG003 : Atlas Copco F9C-11	19/07/2016	Assist in drill repair s
DRG003 : Atlas Copco F9C-11	19/07/2016	Parts
DRG003 : Atlas Copco F9C-11	19/07/2016	Replace top & bottom centraliser jaws
DRG003 : Atlas Copco F9C-11	19/07/2016	Reseal boom lift cyl
DRG003 : Atlas Copco F9C-11	19/07/2016	Run to town pick up parts

DRG003 : Atlas Copco F9C-11	20/07/2016	Refit boom lift cylinder
DRG003 : Atlas Copco F9C-11	20/07/2016	Repalce drifter slide, adjust & change hose reel s
DRG003 : Atlas Copco F9C-11	20/07/2016	Tidy hose up feed rail
DRG003 : Atlas Copco F9C-11	21/07/2016	Assist in drill rig repairs
DRG003 : Atlas Copco F9C-11	21/07/2016	Replace worn hoses, adjust feed chain, refit dust
DRG003 : Atlas Copco F9C-11	22/07/2016	Fit drifter
DRG003 : Atlas Copco F9C-11	22/07/2016	Install Extra cab light, fix door hinge
DRG003 : Atlas Copco F9C-11	22/07/2016	Parts
DRG003 : Atlas Copco F9C-11	22/07/2016	Parts
DRG003 : Atlas Copco F9C-11	22/07/2016	Refit reconditioned duties
DRG003 : Atlas Copco F9C-11	23/07/2016	Run up & check & adjust settings, adjust rod rack
DRG003 : Atlas Copco F9C-11	25/07/2016	Drill repairs to ECG lubrications
DRG003 : Atlas Copco F9C-11	26/07/2016	Service
DRG003 : Atlas Copco F9C-11	29/07/2016	Overhaul Drifter
DRG003 : Atlas Copco F9C-11	31/07/2016	Freight
DRG003 : Atlas Copco F9C-11	4/08/2016	Parts
DRG003 : Atlas Copco F9C-11	7/08/2016	1000 hour service
DRG003 : Atlas Copco F9C-11	7/08/2016	Assist 1000 hour service
DRG003 : Atlas Copco F9C-11	8/08/2016	Parts
DRG003 : Atlas Copco F9C-11	11/08/2016	Drilling maintenace
DRG003 : Atlas Copco F9C-11	12/08/2016	Carry out final 1000hr service & repairs
DRG003 : Atlas Copco F9C-11	13/08/2016	Drill will not start- diagnose
DRG003 : Atlas Copco F9C-11	13/08/2016	Fit panels, add drill rods, tighten drifter bolts
DRG003 : Atlas Copco F9C-11	15/08/2016	Parts
DRG003 : Atlas Copco F9C-11	15/08/2016	Repair coolant leak
DRG003 : Atlas Copco F9C-11	15/08/2016	Test for coolant leak & level sensor
DRG003 : Atlas Copco F9C-11	16/08/2016	Replace header tank hose
DRG003 : Atlas Copco F9C-11	17/08/2016	Parts
DRG003 : Atlas Copco F9C-11	17/08/2016	Parts
DRG003 : Atlas Copco F9C-11	18/08/2016	Coolant level sensor
DRG003 : Atlas Copco F9C-11	18/08/2016	Diagnose eletrical fault with 1000 level coolant
DRG003 : Atlas Copco F9C-11	18/08/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	18/08/2016	Mast repairs
DRG003 : Atlas Copco F9C-11	18/08/2016	Parts
DRG003 : Atlas Copco F9C-11	22/08/2016	Parts
DRG003 : Atlas Copco F9C-11	24/08/2016	Continue with diagnosis of coolant lvel sensor fa
DRG003 : Atlas Copco F9C-11	24/08/2016	Parts
DRG003 : Atlas Copco F9C-11	24/08/2016	Replace water injection valves
DRG003 : Atlas Copco F9C-11	24/08/2016	Town run piack up parts
DRG003 : Atlas Copco F9C-11	25/08/2016	Coolant level sensor, change our sensor
DRG003 : Atlas Copco F9C-11	25/08/2016	Service water, roc oil, comp oil
DRG003 : Atlas Copco F9C-11	26/08/2016	Coolant level sensor fault, check wiring & discusS
DRG003 : Atlas Copco F9C-11	27/08/2016	Replace air flow switch & adjust
DRG003 : Atlas Copco F9C-11	30/08/2016	Repair blown hose & top hyd oil
DRG003 : Atlas Copco F9C-11	1/09/2016	Fabricate dust base
DRG003 : Atlas Copco F9C-11	1/09/2016	Service
DRG003 : Atlas Copco F9C-11	2/09/2016	Parts
DRG003 : Atlas Copco F9C-11	3/09/2016	Fabricate custom dust loose
DRG003 : Atlas Copco F9C-11	5/09/2016	Carry out drill rig repairs, engine oil leak
DRG003 : Atlas Copco F9C-11	12/09/2016	Parts
DRG003 : Atlas Copco F9C-11	14/09/2016	Parts

DRG003 : Atlas Copco F9C-11	14/09/2016	Parts
DRG003 : Atlas Copco F9C-11	14/09/2016	Service
DRG003 : Atlas Copco F9C-11	15/09/2016	RCS fault
DRG003 : Atlas Copco F9C-11	16/09/2016	Assist drill fitter
DRG003 : Atlas Copco F9C-11	16/09/2016	RCS fault
DRG003 : Atlas Copco F9C-11	17/09/2016	RCS fault
DRG003 : Atlas Copco F9C-11	22/09/2016	Replace worn hoses
DRG003 : Atlas Copco F9C-11	23/09/2016	500hr service
DRG003 : Atlas Copco F9C-11	23/09/2016	Changed engine oil & filters
DRG003 : Atlas Copco F9C-11	27/09/2016	Assist with replace tram hose
DRG003 : Atlas Copco F9C-11	27/09/2016	Parts
DRG003 : Atlas Copco F9C-11	27/09/2016	Parts
DRG003 : Atlas Copco F9C-11	27/09/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	27/09/2016	Tramming hoses
DRG003 : Atlas Copco F9C-11	27/09/2016	Weld pipe onto side of dust block
DRG003 : Atlas Copco F9C-11	28/09/2016	Assist hose repair
DRG003 : Atlas Copco F9C-11	28/09/2016	Parts
DRG003 : Atlas Copco F9C-11	28/09/2016	Parts
DRG003 : Atlas Copco F9C-11	28/09/2016	Repalce hose
DRG003 : Atlas Copco F9C-11	28/09/2016	Replace htz hose
DRG003 : Atlas Copco F9C-11	28/09/2016	Weld pipe onto dust vaccume block
DRG003 : Atlas Copco F9C-11	30/09/2016	Batteries
DRG003 : Atlas Copco F9C-11	30/09/2016	Parts
DRG003 : Atlas Copco F9C-11	1/10/2016	Changed tram hose & fitted guard
DRG003 : Atlas Copco F9C-11	3/10/2016	Parts
DRG003 : Atlas Copco F9C-11	10/10/2016	Drill repairs & complete 500hr service
DRG003 : Atlas Copco F9C-11	11/10/2016	Drill repairs, take parts into town
DRG003 : Atlas Copco F9C-11	11/10/2016	Dust collector repairs
DRG003 : Atlas Copco F9C-11	11/10/2016	Parts
DRG003 : Atlas Copco F9C-11	13/10/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	16/10/2016	Repair depth encoder moutning
DRG003 : Atlas Copco F9C-11	18/10/2016	Parts
DRG003 : Atlas Copco F9C-11	18/10/2016	Parts
DRG003 : Atlas Copco F9C-11	18/10/2016	Removal of dustcollector
DRG003 : Atlas Copco F9C-11	18/10/2016	Remove leaking hose
DRG003 : Atlas Copco F9C-11	19/10/2016	Parts
DRG003 : Atlas Copco F9C-11	21/10/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	25/10/2016	Drill repairs
DRG003 : Atlas Copco F9C-11	25/10/2016	Parts
DRG003 : Atlas Copco F9C-11	25/10/2016	Removal of jaw pin
DRG003 : Atlas Copco F9C-11	26/10/2016	Drill repairs
DRG003 : Atlas Copco F9C-11	26/10/2016	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	26/10/2016	Parts
DRG003 : Atlas Copco F9C-11	27/10/2016	Hoses of hose reel
DRG003 : Atlas Copco F9C-11	28/10/2016	Parts
DRG003 : Atlas Copco F9C-11	31/10/2016	Parts
DRG003 : Atlas Copco F9C-11	31/10/2016	Service & TLC
DRG003 : Atlas Copco F9C-11	1/11/2016	Fault repairs
DRG003 : Atlas Copco F9C-11	4/11/2016	Repalced d/c air switch & carr service
DRG003 : Atlas Copco F9C-11	6/11/2016	Organise parts
DRG003 : Atlas Copco F9C-11	8/11/2016	Parts

DRG003 : Atlas Copco F9C-11	9/11/2016	Parts
DRG003 : Atlas Copco F9C-11	10/11/2016	Change drill rods
DRG003 : Atlas Copco F9C-11	10/11/2016	Removal of stack drill rod
DRG003 : Atlas Copco F9C-11	11/11/2016	Service
DRG003 : Atlas Copco F9C-11	11/11/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	13/11/2016	Look at hose reel
DRG003 : Atlas Copco F9C-11	14/11/2016	Drilling
DRG003 : Atlas Copco F9C-11	14/11/2016	Parts
DRG003 : Atlas Copco F9C-11	15/11/2016	Parts
DRG003 : Atlas Copco F9C-11	18/11/2016	Parts
DRG003 : Atlas Copco F9C-11	18/11/2016	Parts
DRG003 : Atlas Copco F9C-11	24/11/2016	Service
DRG003 : Atlas Copco F9C-11	25/11/2016	Service
DRG003 : Atlas Copco F9C-11	26/11/2016	Start 2000hr service
DRG003 : Atlas Copco F9C-11	27/11/2016	2000hr service
DRG003 : Atlas Copco F9C-11	27/11/2016	2000hr service & repairs
DRG003 : Atlas Copco F9C-11	28/11/2016	2000 hour service
DRG003 : Atlas Copco F9C-11	28/11/2016	2000hr service & repairs
DRG003 : Atlas Copco F9C-11	29/11/2016	2000hr service
DRG003 : Atlas Copco F9C-11	29/11/2016	2000hr service
DRG003 : Atlas Copco F9C-11	29/11/2016	Parts
DRG003 : Atlas Copco F9C-11	29/11/2016	Service
DRG003 : Atlas Copco F9C-11	29/11/2016	Service
DRG003 : Atlas Copco F9C-11	30/11/2016	2000hr service
DRG003 : Atlas Copco F9C-11	30/11/2016	2000hr service
DRG003 : Atlas Copco F9C-11	30/11/2016	Assist in repairs
DRG003 : Atlas Copco F9C-11	30/11/2016	Drill repairs
DRG003 : Atlas Copco F9C-11	30/11/2016	Tidy up work area. Drill container & ute
DRG003 : Atlas Copco F9C-11	4/12/2016	Inspection of issue with sensors
DRG003 : Atlas Copco F9C-11	4/12/2016	Investigate electrical fault
DRG003 : Atlas Copco F9C-11	4/12/2016	Repairs, fault diagnose
DRG003 : Atlas Copco F9C-11	6/12/2016	Investigate electrical issue
DRG003 : Atlas Copco F9C-11	6/12/2016	Organise with Atlas to carry out repairs to drill
DRG003 : Atlas Copco F9C-11	7/12/2016	Check A/C & operation
DRG003 : Atlas Copco F9C-11	7/12/2016	Repalce hose
DRG003 : Atlas Copco F9C-11	8/12/2016	Parts
DRG003 : Atlas Copco F9C-11	9/12/2016	Depth counter working
DRG003 : Atlas Copco F9C-11	9/12/2016	Ground Engaging Tools
DRG003 : Atlas Copco F9C-11	10/12/2016	Assist in diagnosis of electrical fault
DRG003 : Atlas Copco F9C-11	10/12/2016	Eelctrical fault
DRG003 : Atlas Copco F9C-11	10/12/2016	Fault finding wiring on boom & repairs
DRG003 : Atlas Copco F9C-11	11/12/2016	Eelctrical fault
DRG003 : Atlas Copco F9C-11	11/12/2016	Wiring fault finding boom chain sprocket & pin
DRG003 : Atlas Copco F9C-11	12/12/2016	Freight
DRG003 : Atlas Copco F9C-11	12/12/2016	Inspect hoses
DRG003 : Atlas Copco F9C-11	12/12/2016	Parts
DRG003 : Atlas Copco F9C-11	12/12/2016	Parts
DRG003 : Atlas Copco F9C-11	12/12/2016	Parts
DRG003 : Atlas Copco F9C-11	13/12/2016	Parts
DRG003 : Atlas Copco F9C-11	14/12/2016	Fit hoses, fit bearing and sproket, ele fault
DRG003 : Atlas Copco F9C-11	14/12/2016	Parts

DRG003 : Atlas Copco F9C-11	14/12/2016	Trouble shoot electrical issue
DRG003 : Atlas Copco F9C-11	16/12/2016	Organise parts
DRG003 : Atlas Copco F9C-11	17/12/2016	Valve adjust, replace reciever fitter in air comp
DRG003 : Atlas Copco F9C-11	21/12/2016	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	30/12/2016	Parts
DRG003 : Atlas Copco F9C-11	3/01/2017	Continue with fault diagnosing & drill not operati
DRG003 : Atlas Copco F9C-11	3/01/2017	Diagnose fault, prep drill track
DRG003 : Atlas Copco F9C-11	4/01/2017	Eelctrical faults
DRG003 : Atlas Copco F9C-11	12/01/2017	Repair stop
DRG003 : Atlas Copco F9C-11	16/01/2017	Check dust flap shaft, hand over
DRG003 : Atlas Copco F9C-11	22/01/2017	Assist replace hoses
DRG003 : Atlas Copco F9C-11	22/01/2017	Fit new sensors replace reel hoses and prep for
DRG003 : Atlas Copco F9C-11	23/01/2017	Assist hose renewal
DRG003 : Atlas Copco F9C-11	23/01/2017	Fitted boom reel & drifter hoses & fittings
DRG003 : Atlas Copco F9C-11	23/01/2017	Parts
DRG003 : Atlas Copco F9C-11	25/01/2017	Check over
DRG003 : Atlas Copco F9C-11	26/01/2017	Hyd leaks/ fittings
DRG003 : Atlas Copco F9C-11	26/01/2017	Repairs, hose change, service
DRG003 : Atlas Copco F9C-11	27/01/2017	Hyd leak, jaws not gripping change sensors cable
DRG003 : Atlas Copco F9C-11	27/01/2017	Rod grippers not working
DRG003 : Atlas Copco F9C-11	28/01/2017	Fine parts
DRG003 : Atlas Copco F9C-11	30/01/2017	Freight
DRG003 : Atlas Copco F9C-11	30/01/2017	Ongoing parts with atlas copco & leading hand
DRG003 : Atlas Copco F9C-11	30/01/2017	Order parts
DRG003 : Atlas Copco F9C-11	30/01/2017	Parts
DRG003 : Atlas Copco F9C-11	30/01/2017	Parts
DRG003 : Atlas Copco F9C-11	30/01/2017	Parts
DRG003 : Atlas Copco F9C-11	30/01/2017	Remove valve block & check
DRG003 : Atlas Copco F9C-11	31/01/2017	Assemble valve block
DRG003 : Atlas Copco F9C-11	31/01/2017	Carry out repairs to drill rig, chase up parts
DRG003 : Atlas Copco F9C-11	31/01/2017	Check hyd filters, fit new clamping valve
DRG003 : Atlas Copco F9C-11	31/01/2017	Filters
DRG003 : Atlas Copco F9C-11	31/01/2017	Parts
DRG003 : Atlas Copco F9C-11	31/01/2017	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	1/02/2017	Diagnose fault with shifter box, remove shifter
DRG003 : Atlas Copco F9C-11	1/02/2017	Filters
DRG003 : Atlas Copco F9C-11	1/02/2017	Run up & test
DRG003 : Atlas Copco F9C-11	1/02/2017	Run up tested replaced hyd filters
DRG003 : Atlas Copco F9C-11	1/02/2017	Tram drill to workshop/assist fitters
DRG003 : Atlas Copco F9C-11	2/02/2017	Pressure cleaned, set up for hoses, repairs
DRG003 : Atlas Copco F9C-11	3/02/2017	Assist vhorse replacment
DRG003 : Atlas Copco F9C-11	3/02/2017	Refit spitter box, sort out housing on cotton
DRG003 : Atlas Copco F9C-11	3/02/2017	Sort out reel hoses with Enzed fit splitter unit s
DRG003 : Atlas Copco F9C-11	17/02/2017	Parts
DRG003 : Atlas Copco F9C-11	18/02/2017	Dust clector not working
DRG003 : Atlas Copco F9C-11	18/02/2017	Electrical issues suction, by pass suction circuit
DRG003 : Atlas Copco F9C-11	20/02/2017	Parts
DRG003 : Atlas Copco F9C-11	21/02/2017	Diagnose & repair hammer operation
DRG003 : Atlas Copco F9C-11	21/02/2017	Issues with pressure switch change
DRG003 : Atlas Copco F9C-11	22/02/2017	Hyd hoses
DRG003 : Atlas Copco F9C-11	22/02/2017	Parts

DRG003 : Atlas Copco F9C-11	22/02/2017	Remove makeup and replace rod gripper hose
DRG003 : Atlas Copco F9C-11	23/02/2017	hoses
DRG003 : Atlas Copco F9C-11	23/02/2017	Parts pick up in broken hill
drg003 : Atlas Copco F9C-11	23/02/2017	Pressure sensors
DRG003 : Atlas Copco F9C-11	23/02/2017	Refit hyd hose
DRG003 : Atlas Copco F9C-11	23/02/2017	Repalce hoses
DRG003 : Atlas Copco F9C-11	23/02/2017	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	23/02/2017	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	1/03/2017	Parts
DRG003 : Atlas Copco F9C-11	3/03/2017	Oil leak
DRG003 : Atlas Copco F9C-11	4/03/2017	Checked hyd leak and made hose
DRG003 : Atlas Copco F9C-11	5/03/2017	Dust collector fault
DRG003 : Atlas Copco F9C-11	7/03/2017	Parts
DRG003 : Atlas Copco F9C-11	7/03/2017	Parts
DRG003 : Atlas Copco F9C-11	7/03/2017	Remove hose
DRG003 : Atlas Copco F9C-11	7/03/2017	Remove hyd hose
DRG003 : Atlas Copco F9C-11	8/03/2017	Hyd hose vaccume issues with sampling
DRG003 : Atlas Copco F9C-11	8/03/2017	Repair blown hose
DRG003 : Atlas Copco F9C-11	10/03/2017	hose
DRG003 : Atlas Copco F9C-11	13/03/2017	Hyd hose on mast, remove & make, replace
DRG003 : Atlas Copco F9C-11	19/03/2017	Electrical issues
DRG003 : Atlas Copco F9C-11	19/03/2017	Engine fault engine shut down
DRG003 : Atlas Copco F9C-11	19/03/2017	Fault finding blown fuse and low oil
DRG003 : Atlas Copco F9C-11	20/03/2017	Drill repairs
DRG003 : Atlas Copco F9C-11	20/03/2017	Electrical issues traming
DRG003 : Atlas Copco F9C-11	20/03/2017	Fault finding wiring issue, parts order
DRG003 : Atlas Copco F9C-11	20/03/2017	Parts
DRG003 : Atlas Copco F9C-11	21/03/2017	Change out rods and shank, top up oils
DRG003 : Atlas Copco F9C-11	21/03/2017	Inspect oil leak
DRG003 : Atlas Copco F9C-11	21/03/2017	Parts
DRG003 : Atlas Copco F9C-11	25/03/2017	Adjust A/C belt
DRG003 : Atlas Copco F9C-11	26/03/2017	Clean and maintain dust extractor filters
DRG003 : Atlas Copco F9C-11	7/04/2017	Clean hyd valve bark/remove hyd hose
DRG003 : Atlas Copco F9C-11	7/04/2017	Hoses & fittings
DRG003 : Atlas Copco F9C-11	7/04/2017	Investigate oil leaks, remove hose
DRG003 : Atlas Copco F9C-11	7/04/2017	Parts pick up
DRG003 : Atlas Copco F9C-11	8/04/2017	Repair oil leaks
DRG003 : Atlas Copco F9C-11	8/04/2017	Replace hyd hose, replace air solenoid valve
DRG003 : Atlas Copco F9C-11	9/04/2017	Reseal valve block onmast.replace dampner swit
drg003 : Atlas Copco F9C-11	10/04/2017	Parts
DRG003 : Atlas Copco F9C-11	14/04/2017	Hyd leak
DRG003 : Atlas Copco F9C-11	15/04/2017	Assist in replacement of jaw
DRG003 : Atlas Copco F9C-11	15/04/2017	Oil leak/ replace rod handler jaws
DRG003 : Atlas Copco F9C-11	23/04/2017	Dust collector issues
DRG003 : Atlas Copco F9C-11	25/04/2017	Assist drill repairs
DRG003 : Atlas Copco F9C-11	26/04/2017	Check sampling operation
DRG003 : Atlas Copco F9C-11	1/05/2017	Assist clean up & hose change out
DRG003 : Atlas Copco F9C-11	1/05/2017	Diagnose hyd oil leaks & carry out repairs
DRG003 : Atlas Copco F9C-11	1/05/2017	Drill repairs
DRG003 : Atlas Copco F9C-11	1/05/2017	Tram back to workshop remove belly plates find
DRG003 : Atlas Copco F9C-11	2/05/2017	Carry out repairs to hose that had fallen

DRG003 : Atlas Copco F9C-11	2/05/2017	Rod handler fault
DRG003 : Atlas Copco F9C-11	3/05/2017	Air & water not working/hoses came off hose dru
DRG003 : Atlas Copco F9C-11	3/05/2017	Retension hoses back onto cottom reel & retensi
DRG003 : Atlas Copco F9C-11	4/05/2017	Blown hyd hose
DRG003 : Atlas Copco F9C-11	10/05/2017	Carry out full inspection of machine, re-calibrate
DRG003 : Atlas Copco F9C-11	10/05/2017	Depth coder fault
DRG003 : Atlas Copco F9C-11	10/05/2017	Parts
DRG003 : Atlas Copco F9C-11	10/05/2017	Sampling issues & rod length calibraition
DRG003 : Atlas Copco F9C-11	11/05/2017	Sort out sample box
DRG003 : Atlas Copco F9C-11	12/05/2017	Dust collector not working
DRG003 : Atlas Copco F9C-11	15/05/2017	Parts
DRG003 : Atlas Copco F9C-11	20/06/2017	Check over machine
DRG003 : Atlas Copco F9C-11	20/06/2017	Wash machine for demobe
DRG003 : Atlas Copco F9C-11	6/09/2017	Entry inspection
DRG003 : Atlas Copco F9C-11	7/09/2017	Parts
DRG003 : Atlas Copco F9C-11	8/09/2017	Adjust rod handler
DRG003 : Atlas Copco F9C-11	8/09/2017	Entry inspection
DRG003 : Atlas Copco F9C-11	8/09/2017	Replace rod handler jaws
DRG003 : Atlas Copco F9C-11	10/09/2017	Depth sensor issues
DRG003 : Atlas Copco F9C-11	10/09/2017	Rod depth sensor
DRG003 : Atlas Copco F9C-11	11/09/2017	Blown hyd hose
DRG003 : Atlas Copco F9C-11	11/09/2017	Depth code fault
DRG003 : Atlas Copco F9C-11	11/09/2017	Organise parts
DRG003 : Atlas Copco F9C-11	11/09/2017	Replace parcusion hose
DRG003 : Atlas Copco F9C-11	13/09/2017	Organise parts
DRG003 : Atlas Copco F9C-11	14/09/2017	Parts
DRG003 : Atlas Copco F9C-11	15/09/2017	Gasket
DRG003 : Atlas Copco F9C-11	15/09/2017	Order parts
DRG003 : Atlas Copco F9C-11	15/09/2017	Reposition head drum hoses and adjust, fix hyd l
DRG003 : Atlas Copco F9C-11	17/09/2017	Change drill shank
DRG003 : Atlas Copco F9C-11	18/09/2017	Depth meter parts
DRG003 : Atlas Copco F9C-11	18/09/2017	Depth meter parts
DRG003 : Atlas Copco F9C-11	19/09/2017	Order parts
DRG003 : Atlas Copco F9C-11	19/09/2017	Parts
DRG003 : Atlas Copco F9C-11	19/09/2017	Shutting down low coolant/coolant leak
DRG003 : Atlas Copco F9C-11	20/09/2017	AM/FM stereo fault
DRG003 : Atlas Copco F9C-11	20/09/2017	Oil cooler gasket
DRG003 : Atlas Copco F9C-11	20/09/2017	Pick up parts
DRG003 : Atlas Copco F9C-11	21/09/2017	Filter housing/radio
DRG003 : Atlas Copco F9C-11	21/09/2017	Order gasket
DRG003 : Atlas Copco F9C-11	21/09/2017	Parts
DRG003 : Atlas Copco F9C-11	22/09/2017	Oil filter houseing gasket
DRG003 : Atlas Copco F9C-11	22/09/2017	Oil filter housing
DRG003 : Atlas Copco F9C-11	26/09/2017	Replace heater hoses
DRG003 : Atlas Copco F9C-11	30/09/2017	Hose and Fittings
DRG003 : Atlas Copco F9C-11	2/10/2017	Jumpstart rig
DRG003 : Atlas Copco F9C-11	2/10/2017	Replace depth sensor
DRG003 : Atlas Copco F9C-11	3/10/2017	Depth sensor
DRG003 : Atlas Copco F9C-11	3/10/2017	Inspect depth sensor/tighten drift mount bolts
DRG003 : Atlas Copco F9C-11	4/10/2017	Hose come off drum/shutting down on low coola
DRG003 : Atlas Copco F9C-11	4/10/2017	Investigate engine shutting down

DRG003 : Atlas Copco F9C-11	5/10/2017	Replace leaking hyd hose/calibrate depth sensor
DRG003 : Atlas Copco F9C-11	8/10/2017	Hyd leak relace hose
DRG003 : Atlas Copco F9C-11	8/10/2017	Replace hose
DRG003 : Atlas Copco F9C-11	9/10/2017	Rod handler sensor bar bent
DRG003 : Atlas Copco F9C-11	10/10/2017	Move from shot to safe spot
DRG003 : Atlas Copco F9C-11	10/10/2017	Organise parts
DRG003 : Atlas Copco F9C-11	12/10/2017	Order enzed replacement stock
DRG003 : Atlas Copco F9C-11	12/10/2017	Parts
DRG003 : Atlas Copco F9C-11	26/10/2017	Hyd hose and fittings
DRG003 : Atlas Copco F9C-11	26/10/2017	Remove and strip cahin motor
DRG003 : Atlas Copco F9C-11	26/10/2017	Remove aned reseal chain
DRG003 : Atlas Copco F9C-11	27/10/2017	Fit chain drive motor
DRG003 : Atlas Copco F9C-11	27/10/2017	Fit chain motor/tension
DRG003 : Atlas Copco F9C-11	6/11/2017	Exit inspection
DRG003 : Atlas Copco F9C-11	6/11/2017	Greg Francis
DRG003 : Atlas Copco F9C-11	6/11/2017	Maintenance on drill rig
DRG003 : Atlas Copco F9C-11	7/11/2017	Top up hyd oil
DRG003 : Atlas Copco F9C-11	8/11/2017	500Hr Service Kit
DRG003 : Atlas Copco F9C-11	8/11/2017	Freight
DRG003 : Atlas Copco F9C-11	9/11/2017	500hr service
DRG003 : Atlas Copco F9C-11	9/11/2017	Carry out 500hr service
DRG003 : Atlas Copco F9C-11	10/11/2017	Finish off 500hr service, replace hyd lines
DRG003 : Atlas Copco F9C-11	10/11/2017	Install belly plate, clean undercarriage
drg003 : Atlas Copco F9C-11	10/11/2017	Parts
DRG003 : Atlas Copco F9C-11	11/11/2017	Blown hose, change out twice. Whyalla for parts
drg003 : Atlas Copco F9C-11	13/11/2017	Parts
DRG003 : Atlas Copco F9C-11	13/11/2017	Poor suction, filter change
DRG003 : Atlas Copco F9C-11	14/11/2017	Order new vac filters
DRG003 : Atlas Copco F9C-11	14/11/2017	Unload bucket & load drill rods
DRG003 : Atlas Copco F9C-11	15/11/2017	Adjust fire ext bracket
DRG003 : Atlas Copco F9C-11	15/11/2017	Organise paperwork for service
drg003 : Atlas Copco F9C-11	15/11/2017	Parts
DRG003 : Atlas Copco F9C-11	16/11/2017	Restock driller with rods
drg003 : Atlas Copco F9C-11	17/11/2017	Oil & Lubricants
DRG003 : Atlas Copco F9C-11	17/11/2017	Put grease in bucket out of cartridges
DRG003 : Atlas Copco F9C-11	20/11/2017	2 x hose weekend call out
DRG003 : Atlas Copco F9C-11	27/11/2017	Rod handler jaws badly worn, weld clamp plates
DRG003 : Atlas Copco F9C-11	27/11/2017	ROD HANDLING JAWS
DRG003 : Atlas Copco F9C-11	3/12/2017	Repair hoses that came out of there brackets
DRG003 : Atlas Copco F9C-11	4/12/2017	Repair hoses that came out of there brackets
DRG003 : Atlas Copco F9C-11	5/12/2017	Replace drum hoses & grease
DRG003 : Atlas Copco F9C-11	6/12/2017	change out shank
DRG003 : Atlas Copco F9C-11	11/12/2017	Order parts as required
DRG003 : Atlas Copco F9C-11	11/12/2017	Parts
DRG003 : Atlas Copco F9C-11	11/12/2017	Parts
DRG003 : Atlas Copco F9C-11	13/12/2017	9754002940 250 Service Kit
DRG003 : Atlas Copco F9C-11	14/12/2017	Change out starter motor & check electrical wirir
DRG003 : Atlas Copco F9C-11	16/12/2017	Move from blast zone
DRG003 : Atlas Copco F9C-11	16/12/2017	Service track
DRG003 : Atlas Copco F9C-11	18/12/2017	parts
DRG003 : Atlas Copco F9C-11	19/12/2017	Check bull hose, required whip check

DRG003 : Atlas Copco F9C-11	7/02/2018	Drill windscreen/ignition
DRG003 : Atlas Copco F9C-11	7/02/2018	Remove front windscreen, remove key switch
drg003 : Atlas Copco F9C-11	9/02/2018	Ignition switch
drg003 : Atlas Copco F9C-11	9/02/2018	Window rubbers
drg003 : Atlas Copco F9C-11	9/02/2018	Window rubbers
DRG003 : Atlas Copco F9C-11	10/02/2018	Cover front window
DRG003 : Atlas Copco F9C-11	10/02/2018	Windscreen cover
drg003 : Atlas Copco F9C-11	12/02/2018	Replace Windscreen
DRG003 : Atlas Copco F9C-11	13/02/2018	Change window and ignition chamber
DRG003 : Atlas Copco F9C-11	13/02/2018	Fit front windscreen
DRG003 : Atlas Copco F9C-11	14/02/2018	Rotate jaw grips, door release button jammed
DRG003 : Atlas Copco F9C-11	15/02/2018	Change rod handler grips, weld
drg003 : Atlas Copco F9C-11	15/02/2018	parts to repair door handle
drg003 : Atlas Copco F9C-11	16/02/2018	parts to repair door handle
drg003 : Atlas Copco F9C-11	19/02/2018	0108 1366 00 Pin
drg003 : Atlas Copco F9C-11	19/02/2018	0500 4500 24 Bearing
drg003 : Atlas Copco F9C-11	19/02/2018	0500 4500 61 Bearing
drg003 : Atlas Copco F9C-11	19/02/2018	3128 2405 00 Shaft
drg003 : Atlas Copco F9C-11	19/02/2018	3128 2407 03 Bushing
drg003 : Atlas Copco F9C-11	19/02/2018	3222 3125 01 Shaft
drg003 : Atlas Copco F9C-11	19/02/2018	3222 3139 59 Cylinder
drg003 : Atlas Copco F9C-11	19/02/2018	3222 3335 18 Cylinder
DRG003 : Atlas Copco F9C-11	20/02/2018	Assisted with loading onto float & unloading
DRG003 : Atlas Copco F9C-11	21/02/2018	Rod handle repairs
DRG003 : Atlas Copco F9C-11	22/02/2018	Rod handler repairs
drg003 : Atlas Copco F9C-11	23/02/2018	Hose for Vac
DRG003 : Atlas Copco F9C-11	23/02/2018	Rod handler repairs & cab door repairs
DRG003 : Atlas Copco F9C-11	24/02/2018	Repairs
DRG003 : Atlas Copco F9C-11	28/02/2018	Rod handler repairs
drg003 : Atlas Copco F9C-11	2/03/2018	Machine parts for rod grippers
DRG003 : Atlas Copco F9C-11	3/03/2018	Rod arm repairs
DRG003 : Atlas Copco F9C-11	4/03/2018	Repairs
DRG003 : Atlas Copco F9C-11	5/03/2018	chain
drg003 : Atlas Copco F9C-11	5/03/2018	Chain and Shackles
DRG003 : Atlas Copco F9C-11	5/03/2018	Repairs
DRG003 : Atlas Copco F9C-11	5/03/2018	Repairs
DRG003 : Atlas Copco F9C-11	6/03/2018	Repairs
DRG003 : Atlas Copco F9C-11	6/03/2018	Repairs
DRG003 : Atlas Copco F9C-11	7/03/2018	Fit new conduct to hoses, build brackets
DRG003 : Atlas Copco F9C-11	7/03/2018	Hyd leak wrap hoses
DRG003 : Atlas Copco F9C-11	8/03/2018	Hyd fitting
drg003 : Atlas Copco F9C-11	8/03/2018	Hydraulic Fitting
drg003 : Atlas Copco F9C-11	8/03/2018	Hydraulic Fitting
DRG003 : Atlas Copco F9C-11	8/03/2018	Installed elbow fitting to rod guide cylinder
DRG003 : Atlas Copco F9C-11	12/03/2018	LOWER CHAIN BEARING
DRG003 : Atlas Copco F9C-11	12/03/2018	ROD CHAIN DIAGNOSIS, REPLACE BOTTOM IDLER
drg003 : Atlas Copco F9C-11	14/03/2018	Hose straps
DRG003 : Atlas Copco F9C-11	15/03/2018	UNBLOCK SUCTION HOSE
drg003 : Atlas Copco F9C-11	31/03/2018	Repiar Vac tube
DRG003 : Atlas Copco F9C-11	6/04/2018	SORT OUT DRILL CONTAINER
DRG003 : Atlas Copco F9C-11	11/04/2018	ELECTRICAL FAULT

drg003 : Atlas Copco F9C-11	12/04/2018	9106142694 Joystick
DRG003 : Atlas Copco F9C-11	12/04/2018	ELECTRICAL FAULT
drg003 : Atlas Copco F9C-11	12/04/2018	Parts for Mast slide modification
drg003 : Atlas Copco F9C-11	13/04/2018	1800-62-1000 Rockdrill oil
DRG003 : Atlas Copco F9C-11	14/04/2018	ORDER PARTS FOR DRILL RIG
DRG003 : Atlas Copco F9C-11	15/04/2018	PUT HOSE BACK OVER DRUM
DRG003 : Atlas Copco F9C-11	16/04/2018	HOSE DRUM ADJUST, REPLACE ENGINE FILTER HO
drg003 : Atlas Copco F9C-11	16/04/2018	Manufacture new hoses
DRG003 : Atlas Copco F9C-11	17/04/2018	HYDRAULIC OIL LEAK
DRG003 : Atlas Copco F9C-11	19/04/2018	REPLACE AIR FITTING
DRG003 : Atlas Copco F9C-11	23/04/2018	INSPECT OIL LEAK, REMOVE ROD GUIDE CYLINDER
DRG003 : Atlas Copco F9C-11	23/04/2018	ORDER PARTS FOR DRG003
drg003 : Atlas Copco F9C-11	26/04/2018	8232300137 Cylinder
drg003 : Atlas Copco F9C-11	26/04/2018	Freight
DRG003 : Atlas Copco F9C-11	27/04/2018	FIT CENTRALISER JAW, FIX CHAIN ADJUSTER, TEN
DRG003 : Atlas Copco F9C-11	28/04/2018	FIT HOSE BACK ONTO DRUM
DRG003 : Atlas Copco F9C-11	30/04/2018	REPAIRS
drg003 : Atlas Copco F9C-11	1/05/2018	ELC Coolant
drg003 : Atlas Copco F9C-11	1/05/2018	Parts for Mast slide modification
DRG003 : Atlas Copco F9C-11	1/05/2018	REPAIRS, 1000HR SERVICE
DRG003 : Atlas Copco F9C-11	1/05/2018	SERVICE
drg003 : Atlas Copco F9C-11	4/05/2018	0663215400 O Ring
drg003 : Atlas Copco F9C-11	4/05/2018	2911011203 Oil Seperator kit
drg003 : Atlas Copco F9C-11	4/05/2018	3214623802 Rubber bag
drg003 : Atlas Copco F9C-11	4/05/2018	3222314125 Air Filter
drg003 : Atlas Copco F9C-11	4/05/2018	8231085345 O Ring
drg003 : Atlas Copco F9C-11	4/05/2018	8231085346 O Ring
drg003 : Atlas Copco F9C-11	4/05/2018	P502231 Filter
DRG003 : Atlas Copco F9C-11	6/05/2018	Change out shank and rods
drg003 : Atlas Copco F9C-11	7/05/2018	Spare Hydraulic Hoses
DRG003 : Atlas Copco F9C-11	12/05/2018	Diagnose & rectify hydraulic oil leak
DRG003 : Atlas Copco F9C-11	28/05/2018	Broken grease fitting, tire up hose bundle
DRG003 : Atlas Copco F9C-11	29/05/2018	Remove drifter
DRG003 : Atlas Copco F9C-11	6/06/2018	Fit drill drifter
DRG003 : Atlas Copco F9C-11	6/06/2018	Unloading drifters, clean mast, fit new drifter
DRG003 : Atlas Copco F9C-11	7/06/2018	Complete fitting of new drifter charged accumulat
DRG003 : Atlas Copco F9C-11	7/06/2018	Gas up accumulators & test run
DRG003 : Atlas Copco F9C-11	8/06/2018	Make up temp hose on mast, organise to have ne
DRG003 : Atlas Copco F9C-11	8/06/2018	nstalled blown off hose to drifter, tested
DRG003 : Atlas Copco F9C-11	9/06/2018	Assess rod handlerjaws, temp weld up handler m
DRG003 : Atlas Copco F9C-11	9/06/2018	Locate inv drill container, diagnose fault with EC
DRG003 : Atlas Copco F9C-11	10/06/2018	Remove & replaced U/S fitting on driller, return ,
DRG003 : Atlas Copco F9C-11	11/06/2018	Assist in diagnosing fault with drifter sensor
DRG003 : Atlas Copco F9C-11	11/06/2018	Diagnose fault with mast length sensor
DRG003 : Atlas Copco F9C-11	12/06/2018	Diagnose wiring fault with mast lights
drg003 : Atlas Copco F9C-11	12/06/2018	hose
DRG003 : Atlas Copco F9C-11	12/06/2018	Inspect tension on hoses & adjust as required
DRG003 : Atlas Copco F9C-11	12/06/2018	Organise repair for parts/bolts
DRG003 : Atlas Copco F9C-11	12/06/2018	Parts
DRG003 : Atlas Copco F9C-11	13/06/2018	Diagnose & repairs electrical fault with work ligh
DRG003 : Atlas Copco F9C-11	13/06/2018	Fix mask lights

DRG003 : Atlas Copco F9C-11	14/06/2018	Diagnose fault with auto drill feed not working, d
DRG003 : Atlas Copco F9C-11	14/06/2018	Hyd fitting on drifter auto drilling fault
DRG003 : Atlas Copco F9C-11	15/06/2018	250hr service
DRG003 : Atlas Copco F9C-11	17/06/2018	Tighten drive chain, check accumulator pressures
DRG003 : Atlas Copco F9C-11	18/06/2018	Charge accumulators
DRG003 : Atlas Copco F9C-11	19/06/2018	Diagnose fault with dust collector/failed fan
DRG003 : Atlas Copco F9C-11	19/06/2018	Dust collector not wokring
DRG003 : Atlas Copco F9C-11	19/06/2018	Parts
DRG003 : Atlas Copco F9C-11	19/06/2018	Remove broken bolts from under carraige
DRG003 : Atlas Copco F9C-11	21/06/2018	Head drive parts, rollers etc
DRG003 : Atlas Copco F9C-11	22/06/2018	Gas up accumulator & check driller
DRG003 : Atlas Copco F9C-11	23/06/2018	Diagnose engine alarm
DRG003 : Atlas Copco F9C-11	24/06/2018	Order parts to carry out injector replacment
DRG003 : Atlas Copco F9C-11	25/06/2018	Parts
DRG003 : Atlas Copco F9C-11	25/06/2018	Travel off site to collect parts as requiried
DRG003 : Atlas Copco F9C-11	26/06/2018	Clean off engine compartment/roder cover
DRG003 : Atlas Copco F9C-11	27/06/2018	500Hr Service Kit
DRG003 : Atlas Copco F9C-11	27/06/2018	Complete injector replacement, replace broken a
DRG003 : Atlas Copco F9C-11	27/06/2018	Install all removed engine parts tension pump
DRG003 : Atlas Copco F9C-11	28/06/2018	Inspect engine
DRG003 : Atlas Copco F9C-11	30/06/2018	Swap over drifters, drill lver faults, drifter
DRG003 : Atlas Copco F9C-11	1/07/2018	Adjust drifter slides, weld up hose brackets back
DRG003 : Atlas Copco F9C-11	1/07/2018	Assisted lifting mast/boom hoses
DRG003 : Atlas Copco F9C-11	3/07/2018	Drum hoses
DRG003 : Atlas Copco F9C-11	3/07/2018	Inspect machine, order parts, retension chain for
DRG003 : Atlas Copco F9C-11	3/07/2018	Parts
DRG003 : Atlas Copco F9C-11	3/07/2018	Parts
DRG003 : Atlas Copco F9C-11	3/07/2018	Parts
DRG003 : Atlas Copco F9C-11	3/07/2018	Parts
DRG003 : Atlas Copco F9C-11	3/07/2018	Repairs/maintenance
DRG003 : Atlas Copco F9C-11	5/07/2018	Chase up parts
DRG003 : Atlas Copco F9C-11	5/07/2018	Clean & return drifter to Atlas/Epiroc
DRG003 : Atlas Copco F9C-11	5/07/2018	Core Return
DRG003 : Atlas Copco F9C-11	5/07/2018	Fix chain links, fix drum hoses
DRG003 : Atlas Copco F9C-11	5/07/2018	Parts
DRG003 : Atlas Copco F9C-11	5/07/2018	Parts
DRG003 : Atlas Copco F9C-11	6/07/2018	Diagnose noise with dust estractor fan
DRG003 : Atlas Copco F9C-11	6/07/2018	Dust collector fan, adjust drum hoses
DRG003 : Atlas Copco F9C-11	6/07/2018	Parts
DRG003 : Atlas Copco F9C-11	7/07/2018	Hose adjust
DRG003 : Atlas Copco F9C-11	7/07/2018	PICK UP PARTS, ONLOAD AND OFFLOAD PARTS
DRG003 : Atlas Copco F9C-11	7/07/2018	Travel hightway to collect parts, adjust hoses & f
DRG003 : Atlas Copco F9C-11	9/07/2018	Broken chain, check accumulator pressures
DRG003 : Atlas Copco F9C-11	9/07/2018	Carry out temp repairs to feeder chain
DRG003 : Atlas Copco F9C-11	9/07/2018	Parts
DRG003 : Atlas Copco F9C-11	9/07/2018	Parts
DRG003 : Atlas Copco F9C-11	9/07/2018	Parts
DRG003 : Atlas Copco F9C-11	10/07/2018	Carry out temporary repairs to chain
DRG003 : Atlas Copco F9C-11	15/07/2018	Drill blown hose
DRG003 : Atlas Copco F9C-11	17/07/2018	Chain issue
DRG003 : Atlas Copco F9C-11	17/07/2018	ID parts need for chain repair

DRG003 : Atlas Copco F9C-11	17/07/2018	Parts - Shanks
DRG003 : Atlas Copco F9C-11	17/07/2018	Pull drum & hoses back into correct position
DRG003 : Atlas Copco F9C-11	19/07/2018	Parts
DRG003 : Atlas Copco F9C-11	20/07/2018	Locate parts & carry out ordering
DRG003 : Atlas Copco F9C-11	20/07/2018	Replace rod handler grip pods & lift drum/hoses
DRG003 : Atlas Copco F9C-11	21/07/2018	Drum hoses
DRG003 : Atlas Copco F9C-11	21/07/2018	Re route hoses onto cotton reel on drill rig
DRG003 : Atlas Copco F9C-11	23/07/2018	Diagnose eng fault shutting down with low oil pressure
DRG003 : Atlas Copco F9C-11	23/07/2018	Shutting down on low oil pressures
DRG003 : Atlas Copco F9C-11	24/07/2018	Hyd hose/hyd leaks
DRG003 : Atlas Copco F9C-11	24/07/2018	Parts
DRG003 : Atlas Copco F9C-11	25/07/2018	Blown hyd hose, drum chain sprocket replace
DRG003 : Atlas Copco F9C-11	27/07/2018	Parts
DRG003 : Atlas Copco F9C-11	28/07/2018	Repairs
DRG003 : Atlas Copco F9C-11	29/07/2018	Repairs
DRG003 : Atlas Copco F9C-11	30/07/2018	Continue with repairs, refit guarding
DRG003 : Atlas Copco F9C-11	30/07/2018	Repairs
DRG003 : Atlas Copco F9C-11	8/08/2018	Repairs
DRG003 : Atlas Copco F9C-11	9/08/2018	Repairs
DRG003 : Atlas Copco F9C-11	10/08/2018	Repairs
DRG003 : Atlas Copco F9C-11	11/08/2018	Finish repairs
DRG003 : Atlas Copco F9C-11	12/08/2018	Change shank & rods. Change top centralizer
DRG003 : Atlas Copco F9C-11	13/08/2018	Cylinder pin and associated parts
DRG003 : Atlas Copco F9C-11	13/08/2018	Cylinder pin and associated parts
DRG003 : Atlas Copco F9C-11	13/08/2018	Make drill
DRG003 : Atlas Copco F9C-11	14/08/2018	Inspect damaged pin
DRG003 : Atlas Copco F9C-11	15/08/2018	Fit new pins
DRG003 : Atlas Copco F9C-11	15/08/2018	Parts
DRG003 : Atlas Copco F9C-11	15/08/2018	Parts
DRG003 : Atlas Copco F9C-11	15/08/2018	Parts
DRG003 : Atlas Copco F9C-11	16/08/2018	Parts
DRG003 : Atlas Copco F9C-11	17/08/2018	Fit new locks to dust collector, replace accumulator
DRG003 : Atlas Copco F9C-11	18/08/2018	Continue with repairs as required
DRG003 : Atlas Copco F9C-11	18/08/2018	Repairs
DRG003 : Atlas Copco F9C-11	19/08/2018	Repairs
DRG003 : Atlas Copco F9C-11	20/08/2018	Parts
DRG003 : Atlas Copco F9C-11	20/08/2018	Repair
DRG003 : Atlas Copco F9C-11	22/08/2018	Parts
DRG003 : Atlas Copco F9C-11	24/08/2018	Fit jaw clamps, wrong ones
DRG003 : Atlas Copco F9C-11	29/08/2018	Bolts 2359651
DRG003 : Atlas Copco F9C-11	29/08/2018	Core Return
DRG003 : Atlas Copco F9C-11	29/08/2018	Eng miss fire
DRG003 : Atlas Copco F9C-11	29/08/2018	injector 10R7222
DRG003 : Atlas Copco F9C-11	31/08/2018	eng missfire
DRG003 : Atlas Copco F9C-11	31/08/2018	Eng missfire
DRG003 : Atlas Copco F9C-11	1/09/2018	Diagnose fault with aircon, found cracked comp
DRG003 : Atlas Copco F9C-11	1/09/2018	Replace no 4 injector adjust a/c belt
DRG003 : Atlas Copco F9C-11	2/09/2018	Refit drum hoses
DRG003 : Atlas Copco F9C-11	2/09/2018	Refit drum hoses to mast
DRG003 : Atlas Copco F9C-11	4/09/2018	Parts
DRG003 : Atlas Copco F9C-11	11/09/2018	3222188152 Air Filter Service Kit

DRG003 : Atlas Copco F9C-11	11/09/2018	9754002940 250Hr Service Kit
DRG003 : Atlas Copco F9C-11	11/09/2018	Diagnose fault with eng missfire
DRG003 : Atlas Copco F9C-11	11/09/2018	Diagnose faulty injector
DRG003 : Atlas Copco F9C-11	11/09/2018	Injector 20R8064
DRG003 : Atlas Copco F9C-11	12/09/2018	Diagnose fault with injector
DRG003 : Atlas Copco F9C-11	12/09/2018	Injector fault
DRG003 : Atlas Copco F9C-11	14/09/2018	WP belt C/O
DRG003 : Atlas Copco F9C-11	15/09/2018	Belt C/O
DRG003 : Atlas Copco F9C-11	16/09/2018	Belt C/O
DRG003 : Atlas Copco F9C-11	16/09/2018	Water pump pulley & belt change out
DRG003 : Atlas Copco F9C-11	17/09/2018	C/O wiper motor
DRG003 : Atlas Copco F9C-11	18/09/2018	Parts
DRG003 : Atlas Copco F9C-11	24/09/2018	Go over machine
DRG003 : Atlas Copco F9C-11	26/09/2018	Parts
DRG003 : Atlas Copco F9C-11	27/09/2018	Overhaul Drifter
DRG003 : Atlas Copco F9C-11	27/09/2018	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	7/10/2018	Repairs
DRG003 : Atlas Copco F9C-11	9/10/2018	Replace rod central jaw arms
DRG003 : Atlas Copco F9C-11	10/10/2018	Assist with drill rig repairs
DRG003 : Atlas Copco F9C-11	10/10/2018	Rod jaw arm repairs
DRG003 : Atlas Copco F9C-11	13/10/2018	Assist with drill rig repairs
DRG003 : Atlas Copco F9C-11	13/10/2018	Repairs
DRG003 : Atlas Copco F9C-11	14/10/2018	Assist with repairs to bottom jaw lines
DRG003 : Atlas Copco F9C-11	14/10/2018	Repairs
DRG003 : Atlas Copco F9C-11	15/10/2018	Assist with repairs as required
DRG003 : Atlas Copco F9C-11	15/10/2018	Repairs
DRG003 : Atlas Copco F9C-11	16/10/2018	Assist with repairs
DRG003 : Atlas Copco F9C-11	16/10/2018	Repairs
DRG003 : Atlas Copco F9C-11	17/10/2018	Parts
DRG003 : Atlas Copco F9C-11	22/10/2018	Fit extractor hose
DRG003 : Atlas Copco F9C-11	4/11/2018	E-stop fault
DRG003 : Atlas Copco F9C-11	5/11/2018	Adjust head sliders & chain measure up hose
DRG003 : Atlas Copco F9C-11	8/11/2018	Parts
DRG003 : Atlas Copco F9C-11	8/11/2018	Replace hose
DRG003 : Atlas Copco F9C-11	9/11/2018	Shank change
DRG003 : Atlas Copco F9C-11	11/11/2018	Fit hose back onto hose drum, blown hose
DRG003 : Atlas Copco F9C-11	11/11/2018	Inspect hyd oil leak & organise repairs
DRG003 : Atlas Copco F9C-11	12/11/2018	Parts
DRG003 : Atlas Copco F9C-11	12/11/2018	Travel to WHY & back, get hose made up
DRG003 : Atlas Copco F9C-11	13/11/2018	Grease fault/no start
DRG003 : Atlas Copco F9C-11	18/11/2018	Refit flose on mast reel
DRG003 : Atlas Copco F9C-11	18/11/2018	Re-installed hose for drifter
DRG003 : Atlas Copco F9C-11	19/11/2018	Overhating issue, wasted & blew out compressor
DRG003 : Atlas Copco F9C-11	19/11/2018	Replace damaged fitting
DRG003 : Atlas Copco F9C-11	20/11/2018	Fix head drums hoses
DRG003 : Atlas Copco F9C-11	20/11/2018	Hose keeps falling off, make plans for repairs
DRG003 : Atlas Copco F9C-11	21/11/2018	Parts
DRG003 : Atlas Copco F9C-11	22/11/2018	A/C not working correctly
DRG003 : Atlas Copco F9C-11	22/11/2018	Inspect air con fault
DRG003 : Atlas Copco F9C-11	24/11/2018	Window refit, 250hr service & defects
DRG003 : Atlas Copco F9C-11	25/11/2018	Assist with repairs to bulb head bucket

DRG003 : Atlas Copco F9C-11	25/11/2018	Blown hose, repairs, 250hr service
DRG003 : Atlas Copco F9C-11	26/11/2018	Assist in refit belly plates & eng cover
DRG003 : Atlas Copco F9C-11	26/11/2018	Repairs, finish 250hr service
DRG003 : Atlas Copco F9C-11	28/11/2018	Parts
DRG003 : Atlas Copco F9C-11	8/12/2018	Inspect leaking hose
DRG003 : Atlas Copco F9C-11	10/12/2018	Drive to Woomera change leaking hoses, repair j
DRG003 : Atlas Copco F9C-11	10/12/2018	Maintenance call out and repair hoses
DRG003 : Atlas Copco F9C-11	10/12/2018	Subcontractor - Plant Maintenance
DRG003 : Atlas Copco F9C-11	11/12/2018	Diagnos eeng oil leak & misfire, drive to Woomer
DRG003 : Atlas Copco F9C-11	11/12/2018	Inspect eng fault, susp maj damage
DRG003 : Atlas Copco F9C-11	11/12/2018	Oil filter
DRG003 : Atlas Copco F9C-11	13/12/2018	Set up for towing
DRG003 : Atlas Copco F9C-11	14/12/2018	Tow off shot for blast
DRG003 : Atlas Copco F9C-11	8/01/2019	MAINTENANCE ON DRG003
DRG003 : Atlas Copco F9C-11	6/02/2019	PACK UP DRILL CONTAINER
DRG003 : Atlas Copco F9C-11	4/05/2019	Load on float
DRG003 : Atlas Copco F9C-11	6/05/2019	Attempt to unload off hoist, fault find tracking p
DRG003 : Atlas Copco F9C-11	6/05/2019	Elec fault no tracking
DRG003 : Atlas Copco F9C-11	6/05/2019	Look for elec fault with tackles
DRG003 : Atlas Copco F9C-11	7/05/2019	Unload from float
DRG003 : Atlas Copco F9C-11	7/05/2019	Unload off truck
DRG003 : Atlas Copco F9C-11	15/05/2019	50T Crane and operator
DRG003 : Atlas Copco F9C-11	15/05/2019	Crane mobilisation Whyalla to Pernatty and retur
DRG003 : Atlas Copco F9C-11	15/05/2019	External - Crane
DRG003 : Atlas Copco F9C-11	15/05/2019	Rigger
DRG003 : Atlas Copco F9C-11	12/06/2019	Organise/park up in yard
DRG003 : Atlas Copco F9C-11	16/07/2019	Upgrade product link
DRG003 : Atlas Copco F9C-11	28/10/2019	Change out batteries/clean up cables
DRG003 : Atlas Copco F9C-11	20/08/2021	PACK UP
DRG003 : Atlas Copco F9C-11	12/10/2021	SOLD PLANT FORMS
DRG003 : Atlas Copco F9C-11	3/12/2021	MOVE DRILL RIG TO WASH BAY
DRG003 : Atlas Copco F9C-11	7/12/2021	LOAD ON FLT
DRG003 : Atlas Copco F9C-11	26/09/2022	TRAINING ON LOADING NEW PROGRAM ONTO D
DRG003 : Atlas Copco F9C-11	27/04/2023	279604 BROKEN SHANK
DRG003 : Atlas Copco F9C-11	4/05/2023	#320827 PREP FOR AUCTION
DRG003 : Atlas Copco F9C-11	4/05/2023	#330158 PREP VEHICLE FOR AUCTION
DRG003 : Atlas Copco F9C-11	5/05/2023	#320199 PREP FOR SALE DIAG START FAULT
DRG003 : Atlas Copco F9C-11	5/05/2023	#329162 PREP FOR SALE CHECK START FAULT REMC
DRG003 : Atlas Copco F9C-11	5/05/2023	#330159 PREP FOR AUCTION
DRG003 : Atlas Copco F9C-11	8/05/2023	#329112 RAISE PO
DRG003 : Atlas Copco F9C-11	8/05/2023	#329163 PREP FOR SALE

aced

e

's

ace

e-oi

scor

ew

ompr
va

ho

ti

se

ller

m

hb

ste

r
s

;

su

ba

oc

arts

f

ang

c

l

ilato

ged

se

l

ed

n
ier

pressor

ut

s

t

p

u

;

ch

hyd

um
on

ea

nt

BEARING

USES

R, COMPI

SION C

or

ew on

ount

|

5

alt

es

t

aw

ra

rn

DRILL

DRIVE & CHARGE BATTERIES