



BOOM PMP

- NSW 2/26 Redfern Street, Wetherill Park 2164
- VIC 12-16 Pelson Court, Dandenong 3175
- QLD 11 Meakin Rd. Meadowbrook 4131
- WA 83-85 Bannister Road, Canning Vale 6155

Ph: 02 9609 8500
 Ph: 03 8773 7000
 Ph: 07 3489 7000
 Ph: 08 6258 0900

90 DAY ANNUAL

DATE: 30-01-2023

OWNER: _____

JOB CARD No. _____

MODEL: SAIL

SERIAL No. 0702106

PLANT No. 1070359

UNIT Hours 872

NOTE: ALWAYS REFER TO AND FOLLOW MANUFACTURERS SPECIFIC MAINTENANCE INSTRUCTIONS AND REQUIREMENTS

AS PER MAINTENANCE/ SERVICE MANUAL

WORK PLATFORM, RAILS, STEPS & GATE (2)(3)(6)	✓	FUEL FILTER (1)(3) (10)if due	N/A
LANYARD ANCHORS (1)(3)(6)	✓	AIR CLEANER (3)(6)(7) (10)if due	✓
BOOMS STRUCTURAL DAMAGE AND WELDS (1)(6)	✓	OIL FILTER (1)(3) (10)if due	N/A
PIVOT PINS, BUSHES, KEEPERS & LOCK DEVICES (1)(3)(6)(8)	✓	FAN BELTS, COOLING SYSTEM (1)(3)(4)(6)(7)(9) (10)if due	N/A
CHASSIS STRUCTURAL DAMAGE AND WELDS (1)(6)	✓	EXHAUST SYSTEM (1)(3)(6)	✓
DOORS, PANELS & COVERS (2)(3)(6)	✓	THROTTLE & SHUTDOWN SOLENOIDS (2)(3)(5)(9)	✓
CHAINS, WIRE ROPES, ROLLERS, ADJUSTERS (1)(2)(6)(9)	✓	ENGINE RPM SETTINGS (2)(9)	✓
SLIDE / WEAR PADS (1)(2)(3)(6)	✓	ENGINE EMERGENCY SHUTDOWN SYSTEM (1)(2)	✓
HOSE & CABLE TRACKS (1)(6)	✓	240V MOTOR & PUMP (1)(2)(3) <u>240V</u>	✓
STEER LINKAGES, PIVOTS & CYLINDERS (1)(2)(3)(6)(8)(9)	N/A	CONTACTORS (1)(2)	✓
WHEELS, TYRES, BEARINGS & NUTS (1)(3)(5)(6)(8) <u>GRAX</u>	✓	BATTERIES & TERMINALS (1)(2)(3)(4)(5)(7)	✓
DRIVE MOTORS & GEAR HUBS (1)(2)(3)(4)(6) (10)if due	X	BATTERY CHARGER / ALTERNATOR (1)(2)(3)	✓
HYDRAULIC BRAKES (2)(6)	✓	CONTROL WIRING LOOMS (1)(6)	✓
HYDRAULIC DISTRIBUTOR (1)(3)(6)	N/A	IGNITION & EMERGENCY STOP SWITCHES (1)(2)(3)	✓
SLEW PINION, GEAR, BOLTS & BRAKE (1)(2)(3)(6)(8)	✓	BASE/PLATFORM SELECT SWITCH (1)(2)	✓
SLEW BEARING & MOTOR (1)(2)(3)(6)(8)	✓	CONTROL SWITCHES / LEVERS, BASE (1)(3)(6)	✓
LIFT & EXTEND CYLINDERS (1)(2)(3)(6)	✓	CONTROL SWITCHES / LEVERS, PLATFORM (1)(3)(6)	✓
BASKET LEVEL & ROTATE CYLINDERS (1)(2)(3)(6)	✓	FOOTSWITCH (2)(6)	✓
OSCILLATING AXLES & CYLINDERS (1)(2)(3)(6)	N/A	HORN (2)	✓
HOSES, FITTINGS & CLAMPS (1)(3)(6)	✓	LIGHTS & BUZZERS (1)(2)(7)	N/A
PRESSURE RELIEF VALVES (2)(3)(5)(9)	✓	MOTION ALARM & FLASHING LIGHTS (1)(2)	✓
ALL HYDRAULIC COMPONENTS (1)(2)(3)(6)(7)	✓	TILT SENSOR (1)(2)(4)(5)(6)	✓
OIL RESERVOIR/HYDRAULIC OIL (1)(4)(6) (10)if due	✓	INTERLOCK SWITCHES, SAFETY CUTOUPS (1)(2)(5)(6)	✓
HYDRAULIC FILTERS (1)(3) (10)if due	✓	OPERATE FUNCTIONS (2)(9)	✓
EMERGENCY LOWERING (2)(6)	✓	FUNCTION SPEED, PROPORTIONAL CONTROLS (2)(5)(9)	✓
AUXILIARY MOTOR & CONTROLS (1)(2)(6)	✓	PLATFORM LOAD SENSE SYSTEM (2)(5)	✓
FUEL TANK (1)(6)	✓	ENVELOPE MANAGEMENT SYSTEM (2)(5)(9)	N/A
ENGINE & PUMP (1)(2)(3)(6)	✓	240 AC OUTLET & ELCB (1)(2)(6)	N/A
ENGINE MOUNTS (3)(6)	✓	AC GENERATOR (2)(3)(5)(6)	N/A

Authorised Serviceperson: DREW

Signature:

CODES:	✓=OK	X=Unsatisfactory	R=Repaired	NA=Not Applicable
1. Visually Inspect		3. Tightness / Security	5. Check Against Specification	7. Clean
2. Check Operation		4. Check Level	6. Condition (wear, rust, damage, cracks, leaks, etc.)	8. Lubricate
				9. Adjust
				10. Replace